



CAS

FACTORY DEFAULT VALUES

- Factory's master code: 5-digit 12345
- Relay time delay 1 and 2: 1 second

NOTE: if the red LED blinks a wrong data was entered in programming mode.

SETTING A MASTER CODE

Do not forget to write down the new master code :

--	--	--	--	--

Enter the default master code twice, the red LED lights on.



Enter 60, then the 5-digit new master code (0 to 9 * and #), the red LED lights off during 1 second.

WARNING : Do not use the master code as a user code. The code 00000 is reserved to delete a user code.

- To exit from the programming mode, press the # key, the red LED lights off.

SETTING USER CODES

Group 1 (relay 1 red LED)

User number

↘	user codes				
00					
01					
28					
29					


Group 2 (relay 2 green led)

User number

↘	user codes				
30					
31					
48					
49					

NB A user code can be programmed in both groups to control simultaneously both relays and with different time delay

SETTING TIME DELAYS




According to the selected mode , enter for each relay 1 and relay 2

- 00 for a latched output
(NOTE: Do not used the latched output in 24V)
- 01 to 99 for a momentary output

The red LED lights off during 1 second

- To exit from the programming mode, press the # key, the red LED lights off.

CANCELLING A USER CODE





- To exit the programming mode, press the # key, the red LED lights off.

RESETTING THE MASTER CODE

Master code : 12345

Note : User codes are still memorized



After 10 seconds, the red LED lights on during 1 second, put back the jumper on 2 and 3, the master code has been reset to the factory default value.

WARNING : This product operates in 12V=/~ (the wire is not cut).
Cut the wire to operate the keypad in 24V=/~.

OPERATING MODE

You have 10 seconds to enter
your user code



As soon as a code is recognized, it activates the
corresponding relay.

NOTE : The 0 digit can be used as an external push button when a clock timer is connected. When the timer is on, pressing on 0 will activate relay 1.
Use relay 2 for another control, for example an alarm.






TECHNICAL SPECIFICATIONS


- Operating voltage 12V =/~ or 24V =/~
 - Consumption :
 - rest : 10mA
 - maximum : 60mA in DC/ 100mA in AC
 - Dimensions : 107 x 87 x 50 mm
 - 2 LED's
 - Protection IP 54
 - Operating temperature : -20°C to +50°C
 - 5-digit master code
 - 50 user codes 2 relay outputs : 30 user codes for relay 1 (red LED)
20 user codes for relay 2 (green LED)
 - Adjustable or latched output
 - 2 relay outputs, 1 N/O & N/C contact, relay 1: 8 amps @ 250 V AC
1 N/O contact, relay 2: 6 amps @ 250 V AC
- (NOTE: Do not used the latched output in 24V)

- Time delay : from 01 to 99 seconds.
- Time delay in programming mode : 120 seconds (if there is no key pressed during 2 minutes, the keypad returns to the stand-by mode
- Time delay to key-in a user code : from 10 to 99 seconds


Wiring diagram

PIN'S FUNCTION


	~/+	12V=~/ or 24V =/~		4	CONTACT NO OF RELAY 2
	~/-			5	COMMON OF RELAY 2
	1	BP/DOOR (NO) - INTERN	NOT DELIVERED WITH THE KEYPAD	6	CONTACT NO OF RELAY 1
	2			7	COMMON OF RELAY 1
	3	CONTACT (NO) - TIMER		8	CONTACT NC OF RELAY 1



WITH FAIL SAFE STRIKES, ELECTROMAGNETS AND STANDARD STRIKE USE 12 or 24V=



PROTECTION:
THIS KEYPAD COMES WITH A VARISTOR. THIS ONE MUST BE INSTALLED ON EVERY OPERATING STRIKE. THE VARISTOR WILL REMOVE ALL INTERFERENCE OR ELECTROMECHANIC FIELDS CAUSED BY THE STRIKE COIL.



PROTECTION:
PUT A 4004 DIODE TO THE STRIKE OR ELECTROMAGNET'S PINS, RESPECTING POLARITIES, TO PROTECT THE APPLIANCE AGAINST SELF EFFECT.

D : 4004 DIODE ( CATHODE EQUIVALENCE  WHITE RING : CATHODE)

E : FAIL SAFE STRIKE OR ELECTROMAGNET

GS : STANDARD STRIKE 12V DC

H : TIMIER CONTACT (OPTIONAL) - TYPE N/O

BP : REQUEST-TO-EXIT (OPTIONAL) - TYPE N/O