

# Installation Manual

Premier 24

Issue 3



**Texecom**  
[www.texe.com](http://www.texe.com)

# Contents

<b>Contents.....</b>	<b>2</b>	<b>5.1 Zone Setup.....</b>	<b>34</b>
<b>1. History.....</b>	<b>4</b>	Zone Types .....	35
<b>2. System Overview .....</b>	<b>5</b>	Zone Attributes 1 .....	36
System Architecture .....	5	Zone Attributes 2 .....	36
Control Panel.....	5	Attributes for Moment or Latch Keys.....	37
Remote Keypads .....	5	Zone Text .....	37
Zone Expanders .....	6	Zone Wiring Type .....	37
Output Expander .....	6	DD 243:2002 .....	37
Communicators .....	6	<b>5.2 Arming Options .....</b>	<b>39</b>
Other Devices .....	7	Timers .....	39
<b>3. Installation .....</b>	<b>8</b>	Arming Modes .....	40
Installation Sequence.....	8	Options .....	40
Control Panel.....	8	Options 1 .....	41
Power Supply Ratings.....	11	Options 2 .....	41
Connecting AC Mains .....	12	Options 3 .....	42
Connecting Batteries .....	12	DD 243:2002 Options .....	42
Connecting Devices to the Network .....	13	<b>5.3 Global Options.....</b>	<b>43</b>
Remote Keypads .....	15	System Timers .....	43
4XP Zone Expander .....	16	System Config. ....	44
iProx Module .....	16	System Options .....	47
8XE Zone Expander .....	17	Monitor Hardware.....	47
8XP Zone Expander .....	18	Control Timers.....	48
24XiD Zone Expander .....	19	System Text .....	48
OP16 Output Expander .....	20	Speaker Tones.....	49
Zone Connections .....	21	<b>5.4 Keypad Setup .....</b>	<b>50</b>
Auxiliary Tamper Connections.....	22	Keypad Zone Mapping .....	51
Speaker Connections.....	22	Keypad Options.....	51
External Sounder Connections.....	23	Keypad Speaker Volume.....	51
Panel Outputs 1 - 8 and PG1.....	24	Keypad Sounder Options.....	51
Wiring a Stand Alone Communicator .....	24	<b>5.5 Expander Setup .....</b>	<b>52</b>
Plug-on Digimodems.....	25	Expander Auxiliary Input .....	53
RP9 Radio-Pad.....	26	Expander Speaker Volume.....	53
PC-Com.....	26	Expander Sounder Options.....	53
UNI-Com .....	26	<b>5.6 System Outputs.....</b>	<b>54</b>
PRINT-Com .....	26	Available Outputs .....	55
GSM-Com .....	26	Programming Outputs.....	55
Connecting a Computer.....	27	Output Group - Not Used .....	55
Connecting a Printer .....	27	Output Group - System .....	55
<b>4. Commissioning and Troubleshooting .....</b>	<b>28</b>	Output Group - Alarm .....	57
Commissioning .....	28	Output Group - Zone .....	59
Trouble-Shooting.....	28	Output Attributes .....	59
Reset and Service Messages.....	30	Custom Output (PGM5-8).....	59
<b>5. Programming the Control Panel .....</b>	<b>31</b>		
Introduction .....	31		
Programming Text.....	33		
Log Off Engineer .....	33		
Reset the Engineers Code (User 00).....	33		

<b>5.7 UDL/Digi Options.....</b>	<b>60</b>
Reset Digi.....	60
Start Test Call .....	60
Program Digi.....	61
Digi Options .....	64
UDL Options.....	65
Radio/SMS Options .....	67
Com Port Setup .....	67
Zone Alarm Reporting Codes.....	68
<b>5.8 Setup Users .....</b>	<b>73</b>
Adding New Users to the System .....	74
Programming New Users .....	74
User Types.....	74
User Options .....	75
User Name Text .....	75
Programming Proximity TAGS .....	75
Deleting User Codes.....	75
Available Options.....	76
<b>5.9 Engineer Utilities .....</b>	<b>77</b>
View Event Log .....	77
Do Bell Test.....	79
Do Walk Test.....	79
View Zone Status .....	80
View System Status .....	80
Confirm Devices .....	80
View RKP Status .....	81
Check Exp. Status.....	81
Set System Time .....	81
Set System Date .....	81
Change Eng. Code.....	82
View iD Status .....	82
Print Log.....	82
Configure Radio.....	83
<b>5.10 Programming Part Arms .....</b>	<b>84</b>
Alter Part Arms.....	84
<b>6. Specifications .....</b>	<b>85</b>
Control Panel .....	85
Remote Keypads.....	86
Zone Expanders.....	86
Output Expanders .....	87
Communicators .....	87
Standards.....	88
Warranty.....	88

# 1. History

This section shows the key milestones in the product development history, helping to identify when particular features were implemented.



**NOTE** To confirm the Panel Type and software version, press **Menu** followed by **4<sub>yes</sub>** on the keypad. The panel type and software version will be displayed.

## Version 1.8

- Support for iD.  
iD wiring supported via **Premier 24iXD Expander**.
- Ability to print the log.  
System log can be printed to serial printer connected to Com port 1.

## Version 2.0

- Software changed for new issue 8 PCB.

## Version 2.02

- GSM UDL enabled.  
Wintex up and downloading supported on **ComGSM**.

## Version 2.04

- Triple EOL (anti mask) support.

## Version 7 – Issue 2 Manual

- EN50131 and DD6662 functionality.  
Features required for EN50131 & DD6662 added – eg keypad blanking.
- Support for **iProx** proximity tag readers.
- Support for **4XP** 4 zone expander.
- Support for Radio Plus.  
**Intelegent Receiver** supported on Com port 2.  
(This is the internal receiver).
- Support for **Premier OP8**.  
On board 8 channel output expander.

## Version 7.1

- Disarm with Radio FOB only after entry.  
Option to prevent unsetting by radio FOB until entry timer started.
- Anti mask works on keypads and expanders.

## Version 7.5 – Issue 2 Manual with Addendum ADD030-3

- PSU Monitor support.  
PSU monitor option on **8XP Expander** auxiliary input.  
**Premier PSU Monitor**.  
**Premier PSU200XP** monitored power supply.
- AC off logged.  
Mains failure recorded in system log.

## Version 7.8


- Support for **RadioPlus Network Receiver**.

## Version 8 – Issue 3 Manual

- 500 event Mandatory Log added.
- Option for silent radio FOB PA.
- Radio shock sensor supported.  
Support for Intelligent Radio Shock Sensor added in preparation for future introduction.
- Additional EOL and TEOL circuits supported.  
Alternative End-of-Line and Triple-End-of-Line resistor values supported for compatibility with other manufacturers products.
- Access users logged.  
Door strike events recorded in the system log.

## 2. System Overview

### System Architecture



### Control Panel

#### Premier 24

- 8 fully programmable Single Pole + Global Tamper or End Of Line zones
- Expandable to 24 zones via keypads and zone expanders
- Up to 4 keypads
- Up to 2 expanders (2 remote or 1 local and 1 remote)
- Up to 1 output module
- 4-wire data network (standard 7/0.2 alarm cable)
- Full arm plus 3 part arms
- Shunt group
- 16 programmable User codes
- 500 Event Log (time & date stamped)
- 500 Event Mandatory Log (time & date stamped)
- 16 character zone text
- 9 programmable outputs (100mA each)
- Facility for Plug-on Digimodem (Com300, Com2400 or ComISDN)
- Facility for Plug-on GSM Module (Premier ComGSM)
- PC-Com/printer port

### Remote Keypads

#### Premier LCD

- 32 character text display
- 2 fully programmable DP or EOL zones
- 1 fully programmable output (100mA -ve applied)
- Fully adjustable back-lighting, normally bright, dim or off, changing to bright during entry or following a key press
- Built in piezo sounder
- Programmable 'Info.' LED

#### Premier LCDL

ALL the features of the *Premier LCD* plus:

- Larger 32 character text display
- Speaker output

#### Premier LCDP

- LCD keypad with a built in Proximity Tag Reader

#### Premier LCDLP

- LCDL keypad with a built in Proximity Tag Reader

## Zone Expanders

### Premier 4XP

- 4 fully programmable DP or EOL zones
- 2 fully programmable outputs (100mA -ve applied each)
- Remotely wired unit

### Premier 8XE

- 8 fully programmable SP or EOL zones
- Plug-on unit

### Premier 8XP

- 8 fully programmable DP or EOL zones
- 8 fully programmable outputs (100mA -ve applied each)
- Speaker output
- Programmable auxiliary input
- Remotely wired unit

### Premier PSU200XP

- Monitored Power Supply with integral **Premier 8XP**

### Premier 24iXD

- 1 loop x 24 fully programmable iD zones
- iD biscuit technology
- Plug-on unit for *Premier 24* only

“iD” is a registered trade mark of Chloride Safety System Limited.

### RadioPlus Intelligent Receiver

- Plug – On receiver for Texecom **RadioPlus** devices.

### RadioPlus Network Receiver

- Network version of the **Intelligent Radio Receiver**.

## Output Expander

### Premier OP16

- 16 fully programmable outputs (100mA each)
- 1 fault output (100mA -ve applied)
- Can be connected to relays and internal sounders

### Premier RM8 Relay Module

- 8 separate inputs for stand alone operation
- 8 x 3Amp relay outputs (n/o, n/c, com)
- Output ‘ON’ LED indication

## Communicators

### Com300

- 8 channel digital communicator supporting Fast Format, Contact ID, SIA Level II and EasyCom Pager protocols
- 300-baud modem for remote uploading and downloading using the *Wintex UDL* software and a PC
- For use with an analogue telephone line (REN = 1)

### Com2400

- 8 channel digital communicator supporting Fast Format, Contact ID, SIA Level II and EasyCom Pager and SMS Messaging protocols
- 2400-baud modem for remote uploading and downloading using the *Wintex UDL* software and a PC
- Sends SMS text messages to mobile phones
- For use with an analogue telephone line (REN = 1)

### ComISDN

- 8 channel digital communicator supporting Fast Format, Contact ID, SIA Level II and EasyCom Pager protocols
- 300-baud (analogue) or 19200-baud (digital) Modem for remote uploading and downloading using the *Wintex UDL* software and a PC
- For use with an ISDN telephone line

### RP9 Radio-Pad

- 8 channel Paknet radio communicator supporting Fast Format and Contact ID protocols
- 4800-baud modem for remote uploading and downloading using the *Wintex UDL* software and a PC

### Premier ComGSM

- True GSM telephone line backup
- Sends SMS text messages to mobile phones
- Arm, Disarm, Reset the alarm, turn outputs on and off, omit zones and send messages to the control panel using SMS text messages
- 9600-baud modem for remote uploading and downloading using the *Wintex UDL* software and a PC

## Other Devices

### **Premier iProx**

- Provides an alternative to Prox keypads for setting & unsetting with a proximity FOB.
- Remote Prox readers available for external or internal use.
- Interfaces with 26 bit **Wiegand** devices.
- Can be used as standalone door entry control

### **PC-Com/USB-Com**

- For connecting a PC to the control panel allowing local uploading and downloading using *Wintex UDL* software

### **UNI-Com**

- For connecting a serial device i.e. PC modem or mobile phone to the control panel

### **PRINT-Com**

- For connecting a serial printer to the control panel

### **RPD-Com**

- For connecting a *RP9 Radio-Pad* to the control panel

### **Premier Battery Splitter**

- Allows two backup batteries to be connected to a single set of battery terminals, and will provide appropriate monitoring and charging for each.

### **External Sounders**

- Texecom supply a range of external sounders

## 3. Installation

### Installation Sequence

Before attempting to install the alarm system, read this section. Once you have an overall understanding of the installation sequence, carefully work through each step.

#### 1: Design the Layout

Make a rough sketch of the premises to get an idea of where the alarm detection devices, keypads, zone expanders etc. are to be located.

#### 2: Mounting the Panel

The control panel should be mounted in a dry area close to an unswitched AC power source and the incoming telephone line (if using the digimodem).



**NOTE** You must complete all wiring before connecting the battery or applying AC mains to the control panel.

#### 3: Install the Keypads and Zone Expanders

Mount and connect the keypads, zone expanders and output modules to the control panel (see page 13 for details).

#### 4: Install the Alarm Detection Devices

Install the detection devices, PIR's, Contacts, PA Buttons etc. and connect them to the control panel (see page 21 for details).

#### 5: Install the External Sounder

Install the external sounder and connect to the control panel (see page 23 for wiring details).

#### 6: Other Wiring

Complete all other wiring including speakers, telephone line and output connections etc. (see pages 22 - 25 for details).

#### 7: Applying Power to the Control Panel

Once steps 1 to 6 are completed, power can be applied to the control panel.

When applying power for the first time, the factory default settings must be loaded (see page 28 for details). Power should always be connected in the following order:

- Connect the red battery lead to the positive terminal of the battery and then connect the black battery lead to the negative terminal



**NOTE** The panel will only become 'live' when the AC Mains is connected or the 'Battery Kick-start' button is pressed.

- Connect the AC mains

For a complete list of factory default settings, see separate Quick Reference Guide INS249 supplied with your panel.

#### 8: Programming the control panel

Please refer to section 5 for instruction on programming the control panel.

#### 9: Testing the System

Test the system thoroughly to ensure that all features and functions operate as required (see page 79 for details).

### Control Panel

#### Mounting

Mount the control panel on a flat, plumb wall using at least three screws of appropriate size.



**NOTE** It is essential to ensure that none of the fixing slots or cable entries are accessible after fixing.

Mains cabling must be secured (e.g. with a cable tie) to one of the anchor points provided.

#### Wiring the Control Panel

### WARNING: ELECTRICITY CAN KILL

**BEFORE connecting the control panel ALWAYS disconnect the supply at the consumer unit. If in ANY doubt consult a qualified electrician.**



**NOTE** ONLY connect the mains supply to the mains terminal block, NEVER connect the mains supply directly to the PCB.

ALWAYS refer to National Wiring Regulations when conducting installation.

An appropriate and readily accessible disconnection device (e.g. an unswitched fused spur) MUST be provided as part of the installation.

The disconnection device must NOT be fitted in a flexible cord.


Where identification of the neutral in the mains supply is NOT possible a two-pole disconnection device MUST be used.

The building mains supply MUST incorporate appropriate short-circuit backup protection (e.g. a fuse or circuit breaker) of High Breaking Capacity (HBC, at least 1500A).


Use mains cable of adequate carrying capacity for the rated current (i.e. at least 0.75mm<sup>2</sup>).



## Control Panel Layout



## Control Panel PCB Layout



### 1: AC Input

Connected to the 16.5V transformer.



**DO NOT CONNECT THE MAINS SUPPLY TO THE AC INPUT TERMINALS ON THE PCB.**

### 2: Battery Connections

A 12V rechargeable battery must be connected to these terminals in order to provide continuous system operation in the event of an AC Mains failure (see page 12 for details).

### 3: Digicom Power

Unfused 12V power output for a stand alone communicator.

### 4: External Sounder Connections

These terminals are used for connecting to an external sounder unit and is protected by a 900mA PTC – F2 (see page 23 for wiring details).

### 5: Network Data Indicators

The red LED indicates that data is flowing out of the control panel and normally flashes very quickly. The green LED indicates that data is flowing into the control panel and normally flashes slowly, the green LED flashes faster as more devices are connected (see page 13 for details).

### 6: Network Connections

The Network provides connection for the keypads and zone expander. The '+' and '-' terminals provide power (protected by a 900mA PTC – F3) whilst the 'T' transmits data and 'R' receives data (see page 13 for wiring details).

### 7: PG1

PG1 is a low current (100mA 've' applied) output (see page 24 for wiring details). The output is also fully programmable (see page 55 for programming details).

### 8: SPK- Loudspeaker Connection

These terminals can be used for connecting up to one 16Ω or two 8Ω loudspeakers (see page 22 for wiring details).

### 9: Auxiliary 12V Power

These terminals are for connecting devices that require 12V power (protected by a 900mA PTC – F4).

### 10: Auxiliary Tamper Connections

These terminals can be used for monitoring the box tamper of auxiliary devices such as power supplies etc. (see page 21 for wiring details).

### 11: Programmable Zones 1 - 8

These terminals provide the connections for the 8 zones (see page 21 for wiring details). Each zone is also fully programmable (see page 34 for programming details).

### 12: Expansion Port

The expansion port is used for plugging on a local zone expander (see page 17 for details).

### 13: Communication Port 2

Com Port 2 is a serial communications port and can be used for connecting various devices.

### 14: Plug-on Digimodem Connections

This socket provides connection for a Com300, Com2400 or ComISDN digimodem (see page 25 for details).

**15: Digicom Inputs**

These terminals a remote reset input and a line fault input and would normally be used when connecting a stand-alone communicator to the control panel (see page 24 for wiring details).

**16: Panel Outputs**

Outputs 1 to 8 are low current (100mA ‘-ve’ applied) and would normally be used when connecting a stand-alone communicator to the control panel (see page 24 for wiring details). Each output is also fully programmable (see page 55 for programming details).

**17: Box Tamper Connection**

The box tamper micro switch is connected here. The micro switch provides tamper protection for the main control panel in case of unauthorised access. To disable the box tamper, remove the micro switch lead and fit a jumper link across the two pins instead.

**18: Tamper Disable Link**

This can be used to disable the box tamper when working with the box lid removed.

**19: Indicator/Power Light**

ON to indicated AC Mains power is present and flashes to indicate that there is an AC Mains failure, also flashes when the plug-on communicator is active.

**20: Communication Port 1**

Com Port 1 is a serial communications port and can be used for connecting a PC running *Wintex*, a *Com2400*, a serial PC modem, a *ComGSM*.

**21: NVM**

All system programming data and the event log is stored in this removable non-volatile memory devices.

**22: Load Defaults Button**

Depress whilst applying power to the control panel to load the factory default settings. Depress and hold for 5 seconds with power already on the panel to restore just the Engineer code to the factory setting of **1** **2<sub>abc</sub>** **3<sub>def</sub>** **4<sub>ghi</sub>**.



**NOTE** Loading the factory default can take up to 30 seconds to complete.

Loading defaults will only be possible if the NVM has not been locked (see page 44 for details).

For a complete list of factory defaults, see INS249 Quick Reference Guide supplied with your panel.

**23: Battery Kick-start pins**

When powering up the panel without AC Mains present, these pins must be shorted in order to connect the battery.

**24: Programming Port**

A flash ROM programmer can be connected here to allow programming of the control panels firmware.

**25: Engineers Keypad**

A portable Engineers keypad can be plugged on here to allow easier access for programming and testing.



**NOTE** When using a keypad as an Engineers keypad, the address must be set to ‘10’ (see page 15 for details).

The keypad zones and cover tamper will not be monitored by the system.

**26: Bell Self Activation Test**

A jumper link should be fitted here to ensure the correct operation of the external sounder. Remove this jumper to remove the 12V bell hold off for testing the bell.

**F2 - F5: Protection Fuses**

The following Electronic Fuses are provided for protection:

- F5 Battery (1.6A)
- F4 Auxiliary 12V Power fuse (900mA)
- F2 Bell/Strobe (900mA)
- F3 Data Network (900mA)

**Power Supply Ratings**

If installing to PD6662, the system standby times in the event of a mains power failure vary depending on the grade and how AC fail is signalled:

System Standby Times		
Grade 2	Grade 3 AC Fail signalled as AC Fail	Grade 3 AC Fail signalled as Fault
12 Hours	12 Hours	24 Hours

The “Rated Power” of the control panel will depend on the size of the standby battery, standby time and the installation grade:

7 Ah Standby Battery			
Max Power Available from control panel	Grade 2 – Rating	Grade 3 – Rating AC Fail signalled as AC Fail	Grade 3 – Rating AC Fail signalled as Fault
750mA	580mA	580mA	290mA
17 Ah Standby Battery			
Max Power Available from control panel	Grade 2 – Rating	Grade 3 – Rating AC Fail signalled as AC Fail	Grade 3 – Rating AC Fail signalled as Fault
750mA	750mA	750mA	710mA

When calculating the current consumption of the system you must include the current taken by the control panel and all the devices that it powers. If the total current exceeds the “Rated Output” for the grade you are installing to then an additional power supply is required.


## Connecting AC Mains

The AC Mains supply is connected to a 3 way 'Euro Type' fused terminal block, which is fitted with a 125mA or 500mA fuse.



**NOTE** All other wiring **MUST** be carried out before AC mains is connected to the control panel.

After connecting the AC Mains, fit the mains cover, this can be found in the spares bag.



## Connecting Batteries

If installing to PD6662: 2004 then only One 12V 7Ah battery or 12V 17Ah battery can be fitted inside the control panel to provide continued operation in the event of an AC mains failure, otherwise, two 12V 7Ah batteries can be connected.



**NOTE** All other wiring **MUST** be carried out before the battery is connected to the control panel.

Connect the red battery lead to the positive terminal of the battery and then connect the black battery lead to the negative terminal.



**NOTE** The panel will only become 'live' when the AC Mains is connected or the 'Battery Kick-start' button is pressed.




OR



OR

If not installing to PD6662: 2004



**NOTE** Two batteries can be fitted and still comply with PD6662:2004 if the **Premier Battery Splitter** is used.

## Connecting Devices to the Network

Before connecting keypads, zone expanders and output modules, isolate ALL power from the control panel (AC Mains & Battery). Do not continue if there is still power present on the control panel.



Connecting devices with power still present on the control panel may damage the device or control panel and invalidate any warranty.

Keypads, zone expanders and output modules are all connected to the same network terminals located at the bottom left hand corner of the control panel and may be connected serially (daisy chain), in parallel (star) or any combination of the two (see Figure 1, page 14 for wiring details).



A maximum of 2 zone expanders, 4 keypads and 1 output module can be connected to the network.

Whenever new devices are connected to the network, they must be confirmed onto the system using the 'Confirm Devices' menu option (see page 80 for details).

## Wiring the Network

The networks are made up of four terminals incorporating power and data. To ensure correct operation, all four terminals on the device must be connected to the corresponding terminals on the control panel, or previous device (see Figure 1, page 14 for wiring details). The table below shows each terminal and its description:

Terminal	Description
+	+12V Supply
-	0V Supply
T	Transmit Data
R	Receive Data

Devices can be connected using 4-core cable. However, it is recommended that 6 or 8-core cable is used as the spare cores can be used to 'Double Up' on the power connections if needed.



Standard 7/0.2 alarm cable can be used for most installations. However, under certain conditions it may be necessary to use screened cable.

## Cable Distances

The maximum recommended distance for devices when using standard 7/0.2 alarm cable is:

- 250m for each branch when using the star (parallel) configuration
- When using a daisy chain (series) configuration the maximum distance will depend on the number of devices connected on the chain. The more devices that are connected, the shorter the distance to the last device (this is due to voltage drop in the cable)

Whichever method of wiring configuration is used, ensure that the voltage between the '+' and '-' terminals at each device is no lower than 10.0V when the system is running on the standby battery.

The table below shows maximum cable runs when one keypad or expander is installed using standard 7/0.2 alarm cable with various loads:

Configuration	Max. Cable Run
1. Keypad + 2 PIR's @15mA	250m
2. Expander + 2 PIR's @15mA	250m
3. Expander + 8 PIR's @15mA	100m
4. As No. 3 + 16Ω Speaker	30m

Distances of up to 1km can be achieved between the control panel and a device. However, a power supply must be installed close to the device to power it locally, this will help to overcome voltage drop caused by the long cable run.

## Overcoming Voltage Drop

There are several ways to overcome voltage drop:

- Use thicker lower resistance cable. Standard 7/0.2 alarm cable has a resistance of 8Ω per 100m
- Double up on the power connections – this will require using a 6 or 8-core cable rather than a 4-core cable
- Install a power supply to power the device locally, remember to common the two negative connections

## Installing a Power Supply

When a power supply is installed, the 0V connections on the power supply must be connected through to 0V on the control panel and the +12V connection between the control panel and the device must be disconnected (see Figure 2, on page 14 for wiring details).

## Network Diagnostics

Each network has two LED's to indicate data flow. The red LED indicates data flowing out of the 'T' terminal and the green LED indicates data flowing into the 'R' terminal. The table below shows each LED status and its meaning:

LED Status	'T' Wire OUT	'T' Wire IN
Red LED Flashing	Normal	Normal
Red LED On	Panel Fault	Cable Short
Red LED Off	Panel Fault	Panel Fault

LED Status	'R' Wire OUT	'R' Wire IN
Green LED Flashing	Panel Fault	Normal
Green LED On	Panel Fault	Cable Short
Green LED Off	Normal	No Data From Devices



The LED's are provided as an aid for fault finding and therefore should not be completely relied upon to indicate that there is a fault.




Figure 1: Network Connections (250m without additional power supply).




Figure 2: Network Connections (1km with additional power supply).

## Remote Keypads

The *Premier LCD*, *LCDL*, *LCDP* and *LCDLP* keypads all have:

- 2 fully programmable zones
- 1 fully programmable –ve applied output
- A fully programmable LED indicator ('Info.' LED)


In addition the *LCDL* and *LCDLP* keypads have:

- A fully adjustable speaker output

The *LCDP* and *LCDLP* keypads also have:

- A built in Proximity Tag/Card reader

## Keypad Layout



## Connecting Keypads

Keypads are connected to the network terminals located at the bottom left hand corner of the control panel (see pages 13 & 14 for connection details).

## Keypad Addressing

Each keypad must be assigned a different address using the DIL switches located on the left hand side of the PCB. The table below shows the keypad addressing:

Address	DIL 1	DIL 2	DIL 3	DIL 4	
1	On or off	Off	Off	Off	
2	Off	On	Off	Off	
3	Off	Off	On	Off	
4	Off	Off	Off	On	
Engineers	On	On	On	On	



Never set two keypads on the same network to the same address.

When using a keypad as an Engineer's keypad, the DIL switches must all be 'On'.

## Zone Numbering

The table below shows the zone allocation when the keypads are installed:

Address	Zones (Network 1)	Zones (Network 2)
1	Unmapped	Unmapped
2	Unmapped	Unmapped
3	Unmapped	Unmapped
4	Unmapped	Unmapped



The zones inside the keypads are not seen by the system until they have been mapped to a zone number (see page 51 for details).

## Keypad Zones

The keypad has two programmable zones (see page 21 for wiring details). Each zone is also fully programmable (see page 34 for programming details).

## Keypad Output

The remote keypad has one programmable output, which can be used to drive auxiliary devices such as LED's, sounders or relays etc. Wire as per Panel Outputs shown on page 24 (see page 53 for programming details). The electrical characteristics for the output are shown below:

Output	Max Current	Type
1	100mA	Switched -ve

## Keypad Speaker Output (LCDL/LCDLP Only)

The *Premier LCDL* and *Premier LCDLP* keypads have an output that can be used for driving up to one 16Ω or two 8Ω loudspeakers (see page 22 for wiring details).



The speaker volume is also fully adjustable (see page 51 for details).

## Programmable 'Info.' LED

The 'Info.' LED on the front of the keypad can be programmed to mimic the keypad output or show the armed status of alarm (see page 51 for details).

## Adjustable Backlighting

To adjust the keypad backlighting press the **YES** key for 5 seconds, then with the **YES** key still pressed use to increase or decrease the backlighting until the required brightness is achieved, then release both keys.




The backlight can only be adjusted when the keypad is not in a menu.

## Keypad Lid Tamper

The lid tamper of each keypad can be disabled if required using the relevant keypad option in the Keypad Setup menu (see page 51 for details).

4XP Zone Expander

Expander Layout



Connecting Expanders

Expanders are connected to the network terminals located at the bottom of the control panel (see pages 13 & 14 for details).

Addressing

4XP expanders are addressed as one or (normally) two keypads on the network. Each 4XP has to have a unique address, which must not conflict with any keypad or any other 4XP on the same network.

The following table shows the expander addresses & the keypad slots that each would occupy.

Address	DIL 1	DIL 2	DIL 3	DIL 4	Keypads
1	On	off	off	off	1 & 2
2	off	On	off	off	2 & 3
3	off	off	On	off	3 & 4
4	off	off	off	On	4 (2 Zones)

Zones

The 4XP provides 4 alarm zones, 2 for each of the 2 keypad slots it occupies. Each zone is fully programmable (see page 35) and has to be mapped to the system (see page 51).

Outputs

2 Programmable outputs are provided 1 for each of the 2 keypad slots occupied by the expander (see page 54 for output programming)

Expander Speaker Output

One speaker output is provided for connecting one external 16Ω or 2 8Ω loudspeakers (see page 22 for details).

The speaker volume is programmed through the keypad setup menu (see page 51)


**NOTE** The speaker is available on keypad 1 of the two keypad slots the 4XP occupies. (ie if the 4XP address is 3, the speaker will be programmed as belonging to keypad 3).

Expander Com Port

The Com Port can be used to connect a **RadioPlus Intelligent Receiver**.

iProx Module

iProx Layout



Connection

The **iProx Module** is connected to the network terminals located at the bottom of the control panel (see pages 13 & 14 for details).

Addressing

The **iProx Module** is addressed as a keypad and will occupy a keypad slot on the network. The unit must have a unique address, which must not conflict with keypad or any other **iProx Module** on the same network

The following table shows the addressing:

Address	DIL 1	DIL 2	DIL 3	DIL 4
1	On	off	off	off
2	off	On	off	off
3	off	off	On	off
4	off	off	off	On

Refer to the **iProx Module** manual for programming and operating instructions.




## 8XE Zone Expander

The Premier 8XE Zone Expander has:

- 8 fully programmable zones
- Aux 12V Output


### Expander Layout



### Connecting Expanders

The 8XE local zone expander plugs directly on to the terminals located on the right hand side of the control panel (see below for details). To install the local zone expander proceed as follows:

1. Ensure that all power is removed from the control panel (mains and battery) before attempting to fit the expander.
2. Push the four support pillars (supplied) into the four locating holes on the control panel PCB.
3. Align the local expander connector with the 8 way plug (JP6) on the control panel. Push expander into place, ensuring that all four pillars clip into the four locating holes on the local expander.



### Zone Numbering

The table below shows the zone allocation when the expanders are installed:

Configuration	Panel Zones	Expander Zones
8XE = Zones	1 to 8	9 to 16
8XE= Tamper	1 to 8	Tampers 1 to 8

### Expander Zones


The expander has eight programmable zones (see page 21 for wiring details). Each zone is also fully programmable (see page 34 for programming details).

## 8XP Zone Expander

The Premier 8XP Zone Expander has:

- 8 fully programmable zones
- 8 fully programmable –ve applied outputs
- 1 programmable auxiliary input
- A fully adjustable speaker output

### Expander Layout



### Connecting Expanders

Expanders are connected to the network terminals located at the bottom left hand corner of the control panel (see pages 13 & 14 for connection details).

### Expander Addressing

Each Expander must be assigned a different address using the DIL switches located in the centre of the PCB. The table below shows the expander addressing:

Address	DIL 1	DIL 2	DIL 3	DIL 4	
1	On or off	Off	Off	Off	
2	Off	On	Off	Off	

**NOTE** Never set two expanders on the same network to the same address.

### Zone Numbering

The table below shows the zone allocation when the expanders are installed:

Address	Zones
1	9 - 16
2	17 - 24

### Expander Zones

The expander has eight programmable zones (see page 21 for wiring details). Each zone is also fully programmable (see page 34 for programming details).

**NOTE** When using an 8XP Zone Expander, the wiring configuration must always be selected as 'Double EOL' even if wired as Double Pole.

### Expander Auxiliary Input

The expander has one programmable input. This auxiliary input can be used to monitor auxiliary devices such as tamper loops etc. Wire as per Aux Tamper shown on page 22 (see page 53 for programming details). The system will respond as follows:

Input Status	System Response
0V Applied	Input Secure
0V Removed	Input Active

**NOTE** For further details on how the input status affects the system please refer to page 53.

### Expander Outputs

The zone expander has eight programmable outputs, which can be used to drive auxiliary devices such as LED's, sounders or relays etc. Wire as per Panel Outputs shown on page 24 (see page 53 for programming details). The electrical characteristics for the outputs are shown below:

Outputs	Max Current	Type
1 to 8	100mA	Switched -ve

### Expander Speaker Output

The expander has an output that can be used for driving up to one 16Ω or two 8Ω loudspeakers (see page 22 for wiring details).

### Expander Com Port

The Com Port can be used to connect a **PSU200** monitored power supply or a **RadioPlus Intelligent Receiver**.

### Expander Lid Tamper

The lid tamper of each expander can be disabled if required by fitting a jumper link across the centre and right hand pins of the 'Enable Tamper' pins (JP2) leaving the left hand pin free. These pins are located to the left of the address DIL switch just beneath the fuse.

## 24XiD Zone Expander

One 24XiD expander can be connected to the Premier 24 to provide 1 iD loop supporting up to 24 biscuits.


### Installation

Before connecting the 24XiD expander module, isolate ALL power from the control panel (AC mains and battery), do not continue if there is still power present on the control panel.

1. Plug the expander onto the control panel, see 24XiD installation manual for details.
2. Connect the iD devices to the expander module, see "iD Connections".
3. Reapply power to the control panel and program the necessary options on the panel see 24XiD installation manual for details.

### iD Connections

Each iD biscuit is connected across a two-wire detector loop. Apart from observing the correct polarity, any wiring configuration can be used, as shown in the diagram below:



\* The 24XiD expander module is supplied with 4 off 10nF capacitors in the spares pack. It is recommended that you connect a 10nF capacitor approximately at the half way point of each iD spur. It is especially important to do this on iD spurs that are less than 30 metres.

### Cabling Considerations

The iD loop can be wired using standard 4-core alarm cable, this allows 2 cores to be used for the iD biscuit and 2 cores for supplying 12V power for PIR's etc.

The number of biscuits that can be connected per cable run is determined by the impedance of the cable used. Standard 4-core alarm cable (7/0.2mm) has a resistance of approximately 8 Ohms per 100 metres. The following table shows the maximum number of biscuits that can be connected at the end of a single cable run using standard 4-core alarm cable:

Cable Length	Maximum Number of Biscuits
100m	30
200m	15
400m	7
800m	3

If a different type of cable is used, the distances should be re-calculated. e.g., if 7/0.4mm cable is used, a single run of 200m would support 30 devices on the end as the resistance of the cable is halved.


When installing the iD loop it is usually more practical to run several cables from the expander module to the different areas of protection. This effectively reduces any distance problems and makes fault finding much easier.

To reduce the risk of induced interference and wherever possible, cables should not be positioned along side mains power, telephone or other data transmission cables, or run within the same ducting or trunking as any other cables.

The wiring for the system's internal sounders (loudspeakers) should not be connected in the same multi-core as the iD loop.


### Biscuit Connections

Each iD biscuit is identified by its own number 01 to 30 and contains its own internal sensor that is continuously monitored by the expander module. The diagram below shows the connections to the biscuit for monitoring both tamper and alarm contacts.



When the tamper switch is opened, the iD biscuit is taken offline and a tamper condition is generated by the control panel. If the alarm switch is opened the biscuit's internal sensor changes state and the control panel will see this as an active condition and will respond as appropriate.

The diagram below shows the typical wiring of a biscuit to a standard PIR.



"iD" is a registered trade mark of Chloride Safety System Limited.


# OP16 Output Expander

A maximum of 1 output module can be connected to the network along with keypads and zone expanders.

The Premier OP16 output module can be set up to mimic the outputs of zone expanders.

**NOTE** In order for an output module to mimic zone expander outputs, the output module must be addressed the same as the zone expander that it is mimicking.

## Output Module Layout



## Connecting Output Modules

Output modules are connected to the network terminals located at the bottom left hand corner of the control panel (see pages 13 & 14 for connection details).

## Output Module Addressing

Each output module must be assigned a different address using the DIL switches located in the centre of the PCB.

**NOTE** Bank 1 switch sets the address of the device that Bank 1 outputs 1 to 8 will mimic.

**NOTE** Bank 2 switch sets the address of the device that Bank 2 outputs 1 to 8 will mimic.

The table below shows the output module addressing:

Address	DIL 1	DIL 2	DIL 3	DIL 4	
1	On or off	Off	Off	Off	
2	Off	On	Off	Off	

## Output Module Numbering

The table below shows the output allocation when the output modules are installed:

Address	Outputs
1	Expander 1, 1 - 8
2	Expander 2, 1 - 8

## Outputs

The output module has 16 programmable outputs, which can be used to drive auxiliary devices such as LED's, sounders or relays etc. Wire as per Panel Outputs shown on page 24 (see page 53 for programming details). The electrical characteristics for the outputs are shown below:

Bank	Outputs	Max Current	Type
1	1 to 8	100mA	Switched -ve
2	1 to 8	100mA	Switched -ve

## Tamper Output


The tamper switch on the output module is connected to the tamper output at the top of the module. If monitoring of the lid tamper is required, this output must be connected to a suitable input on the control panel or zone expander.

## Zone Connections

Any zones that are not being used must be linked out or programmed as 'Not Used' (see page 34 for details).

### Normally Open or Normally Closed


Use this wiring configuration when connecting normally closed or normally open detection devices to the zone using 2-Wires.



When using this configuration the tampers must be wired to the Aux tamper input (see page 22 for details).

### Double Pole

Use this wiring configuration when connecting normally closed detection devices to the zone using 4-Wires.




When using this configuration, no more than 10 detectors can be connected to each zone.

When wiring double pole (4-wires) to a keypad or zone expander, the wiring configuration must always be programmed as 'Double Pole/EOL'.

### End Of Line


Use this wiring configuration when connecting normally closed detection devices to the zone using 2-Wires. Zone wiring should be programmed as Double Pole/EOL.



When using this configuration, no more than 3 detectors can be connected to each zone.

## Triple End Of Line (TEOL)

Use this wiring configuration when connecting PIR devices with that require Anti Mask and Fault detection. Several zone wiring programming options are available for this, Triple EOL is illustrated below.




When using this configuration, only 1 detector can be connected to each zone.



Alternative resistor values are available – see **Zone Wiring Types** on page 37 for more details.

## Speaker Connections


This output can be used for driving up to one 16Ω or two 8Ω loudspeakers as shown below:



For details on testing Speaker outputs, see page 79

## Auxiliary Tamper Connections

The Auxiliary Tamper terminals allow the control panel to monitor the tamper loops of external devices such as power supplies etc.



If the 'Auxiliary Tamper' terminals are not being used they must be linked out.

## External Sounder Connections

The following terminals have been provided for connection to an external sounder:

### **(A) +12V**

12V supply (protected by a 900mA PTC – F2). Normally connected to '+12V' on the sounder.

### **(B) Bell –**

Sounder output, switches to 0V in alarm (SAB) and is rated at 500mA. Normally connected to Trigger -ve on the sounder. This output can also be programmed for SCB operation (see page 44 for details).

### **(C) Tamp**


Negative tamper return. Normally connected to 'Tamper Out' on the sounder. If this terminal is not being used, it must be connected to '0V'.

### **(D) 0V**

0V supply. Normally connected to '0V' on the sounder.

### **(S) Strb –**

Strobe output, switches to 0V in alarm and is rated at 500mA. Normally connected to strobe -ve on the sounder (where applicable, connect the strobe +ve to +12V).



**NOTE** For details on testing the 'Bell' outputs, see page 79

When an Engineers code is entered to gain access to the programming menu, the Strobe output will pulse 3 times, invoking Engineers Hold Off mode if a Texecom bell box is connected.


Panel Outputs 1 - 8 and PG1

The control panel has 8 programmable outputs, which can be used to drive auxiliary devices such as LED's, sounders or relays etc. (see page 55 for programming details). The table below shows the electrical characteristics for each output:

Terminal	Max Current	Operation
1	100mA	Switched 0V
2	100mA	Switched 0V
3	100mA	Switched 0V
4	100mA	Switched 0V
5	100mA	Switched 0V
6	100mA	Switched 0V
7	100mA	Switched 0V
8	100mA	Switched 0V
PG1	100mA	Switched 0V
L/M	N/A	0V removed = Line Fault
R/R	N/A	0V applied to reset
DC+	N/A	+12V Power (unfused)
DC-	N/A	0V Power

Wiring Outputs

The diagram below shows some typical wiring examples:



NOTE For details on testing outputs, see page 79.


Wiring a Stand Alone Communicator

The panel outputs can be used to trigger a stand alone digital communicator.

The default outputs are shown in the following table, see page 55 for details of how to program outputs.

Panel Output	Function
1	Fire Alarm
2	PA Alarm
3	Intruder Alarm
4	Armed
5	Zones Locked Out
6	Fault Present
7	Confirmed Alarm
8	Abort

The diagram below shows a typical wiring example:



NOTE For details on testing the outputs, see page 79.



## Plug-on Digimodems

The *Com300* is a multi format 8-channel digital communicator/300-baud modem for use with a standard analogue telephone line.


The *Com2400* is a multi format 8-channel digital communicator/2400-baud modem for use with a standard analogue telephone line in addition, this modem can also send Short Message Service (SMS) text messages to a mobile phone.

The *ComISDN* is a multi format 8-channel digital communicator/modem for use with an ISDN telephone line.

These Digimodem can be used to report system events to an Alarm Receiving Centre using Fast Format, Contact ID or SIA Level II or to upload/download control panel information using the *Wintex UDL* software and a PC.

## Plugging on the Digimodem


Ensure that the board is the correct way up (see below). Locate the eight-pin plug into the digimodem socket on the control panel and line up the mounting holes with the pillars in the base. Once all the holes line up, press down gently until the pillars snap into the holes.



Left side of Premier 24


## Standard Telephone Line Connections

A standard telephone line must be connected to the *Com300* or *Com2400* digimodem as shown below:



## ISDN Telephone Line Connections

An ISDN telephone line must be connected to the *ComISDN* digimodem as shown below:



NOTE

For details on testing the digimodems, see page 60.

## RP9 Radio-Pad

Before connecting the *Radio-Pad*, isolate ALL power from the control panel (AC mains and battery), do not continue if there is still power present on the control panel.

To install the *Radio-Pad* onto the control panel:

- Connect the 7-Way connector of the *RPD-Com* lead to Com2 on the control panel
- Connect the 25-Way D-Type connector of the *RPD-Com* to the Radio-Pad
- Locate the power lead connector into the socket at the bottom of the Radio-Pad
- Connect the Black lead to the DC- terminal on the control panel
- Connect the lead with the White stripe to the DC+ terminal on the control panel
- Follow the procedure for **Registering the Radio-Pad**

## Registering the Radio-Pad

Whenever a Paknet Radio-Pad is installed or moved, it must be **registered** onto the network. To do this:

- Press and hold the test button on the front of the Paknet Radio-Pad
- With the test button still pressed, connect power to the control panel and wait for the yellow service light on the Radio-Pad to flash
- Release the test button

Within 2 minutes the yellow service light should stop flashing and remain steady. This means that the Paknet Radio-Pad has now selected and locked on to the Base Station with the strongest signal.


The Paknet Radio-Pad should be re-registered on every site visit, this is to ensure that any new Vodafone Packet Radio Service Base Stations in the vicinity are recorded by the Paknet Radio-Pad.

## Programming the Radio-Pad

- Program Com 2 for *Radio-Pad* operation (see page 67 for details)
- Refer to the *Radio-Pad* installation guide for full programming details.


## PC-Com

The *PC-Com* has two connectors. The 9-way D-type connector is for connection to a serial port on a computer and the 5-way Molex connector plugs onto Com 1 on the control panel.




## UNI-Com

The *UNI-Com* has two connectors. The 9-way D-type connector connects to any supported serial device, the 5-way Molex connector plugs onto Com 1 on the control panel.




## PRINT-Com

The *PRINT-Com* has two connectors. The 25-way D-type connector connects to a Serial Printer and the 5-way Molex connector plugs onto Com 1 on the control panel.



## GSM-Com

The *GSM-Com* has four connectors. The RJ45 connector connects to the GSM Module, the 7-way Molex connector plugs onto Com 2 on the control panel, the 5-way Molex connector plugs onto the Audio connector on a Com300 or Com2400 and the jack plug connects to the power connector on the GSM Module to provide power (5V).



## Connecting a Computer

The *Premier 24* supports local uploading and downloading between the control panel and a PC running *Wintex UDL* software. Uploading and Downloading can be used to program and interrogate the control panel.


In order for the computer to work correctly, ensure that it is set to the following:

- UDL Password (see page 66 for details)



NOTE

In order to upload and download to the control panel locally, a *PC-Com* lead is required.



## Connecting a Printer

The *Premier 24* supports printer facilities. The printer is connected to the Com 1 connector located on the control panel and can be used to print the control panel event log.


In order for the printer to work correctly, ensure that it is set to the following:

- Baud Rate = 4800
- Parity = None
- Start Bits = 1
- Stop Bits = 2
- Data Bits = 8
- DTR = Normal
- Columns = 40 or 80 (see page 44)



NOTE

In order to connect a printer to the control panel, a *PRINT-Com* lead is also required.



## 4. Commissioning and Troubleshooting

### Commissioning

Once ALL connections have been made to the control panel and power is ready to be applied, you should read this section before continuing.

**When applying power for the first time, the factory default settings must be loaded. The default settings ensure that the control panel software is reset and all programming information is loaded into memory. For a complete list of factory default settings, see INS 249 Quick Reference Guide supplied with your panel.**

The factory default settings are loaded by applying power to the control panel whilst at the same time, holding down the **Factory Default** button.

To default the control panel, proceed as follows:

- Connect the black battery lead to the negative (-) terminal of the standby battery and the red battery lead to the positive (+) terminal of the standby battery
- Press and hold the **Factory Default** button
- Press the battery kick-start button to connect the battery and ensure that the green power light illuminates
- After the power light has illuminated, let go of the **Factory Default** button (the power light will continue to flash whilst the factory default settings are being loaded, this can take up to 30 seconds)
- If the system goes into alarm, **enter the default Engineer code** ① ②<sub>abc</sub> ③<sub>def</sub> ④<sub>ghi</sub>, and the alarm tone will stop
- To access the Engineer Programming Menu, **enter the default Engineer code** ① ②<sub>abc</sub> ③<sub>def</sub> ④<sub>ghi</sub>
- Program the system as described in section 6 (Programming the Control Panel)
- Perform a zone test as described on page 79. Remember that some powered detectors (e.g. PIR's and combined technology detectors) take several minutes to warm up and become operational
- Test the internal sounder, external sounder and strobe as described on page 79
- Replace the lid and secure with the lid screw supplied
- **Press** ① followed by **YES** to leave the programming menu, the system will return to normal
- The display will be showing that there is a 'Mains Power Off' condition. Switch on the AC mains supply to the control panel
- The normal banner message (if programmed) will now be displayed

**Installation is now complete and the system is ready for use.**

### Trouble-Shooting

#### Control Panel

##### No Power to unit (mains only)

- Check the mains block fuse and replace if blown
- Check for loose wires at the mains block, the transformer and the AC terminals on the PCB
- Check the mains block is connected correctly; live to live (brown), neutral to neutral (blue)

##### No Power to unit (battery only)

- Don't forget to press the battery kick-start button
- Check the battery PTC LED for faults
- Check for loose wires at the BATT terminals on the PCB
- Check that the battery wires are connected correctly; red from BATT+ to the battery positive (+), black from BATT- to the battery negative (-)

##### Network Data LED's are not flashing

- Remove ALL power (AC Mains and Battery) and remove ALL wires from the network terminals. Then re-apply power again before referring to the Network Diagnostics table on page 13

##### External Sounder not Functioning (No 12V Output)

- Ensure that JP9 is fitted, as without this jumper link there will be no 12V power from the 12V Bell Terminals.

### Keypads

#### Keypad does not operate

- Check that the keypad is wired correctly from the control panel (see page 13 for wiring details)
- Check the network PTC LED for faults
- Use the network diagnostics (see page 13 for details)

#### Keypad does not accept codes

- If the system has more than one keypad check that each keypad is addressed differently, see page 15 for details
- If the keypad is on a long cable run, check the voltage between the '+' and '-' terminals at the keypad and ensure that it measures no less than 10.0V
- Check that you are using the correct User codes. The default Engineer code is ① ②<sub>abc</sub> ③<sub>def</sub> ④<sub>ghi</sub> and the default Master User code is ⑤<sub>jkl</sub> ⑥<sub>mno</sub> ⑦<sub>pqrs</sub> ⑧<sub>tuv</sub>
- Check that the User code you are using is not 'Locked', if the User code is locked then the access code will only be accepted when the PGM is off (see page 47 for details)

**Keypad zones do not operate**

- Each keypad zone has to be mapped onto the system before it can be used (see page 51 for details)
- The zone is not programmed (see page 34 for details)

**Keypad emergency keys do not operate**

- Each keypad can be configured so that the emergency keys **PA**, **FIRE** and **MEDICAL** can be enabled or disabled. Check that the keypad has been programmed correctly (see page 51 for details)

**Expander****Expander does not operate at all**

- Check that the expander is wired correctly from the control panel (see page 13 for wiring details)
- Check the network PTC LED for faults

**System does not recognise zones**

- If the expander is on a long cable run, check the voltage between the + and – terminals at the expander and ensure that it measures no less than 10.0V

**The speaker output does not work**

- The expander can be configured so that Alarm, Entry, Exit, Chime tones etc. can be enabled or disabled. Check that the expander has been programmed correctly (see page 53 for details)
- The speaker volume on the expander is electronically adjustable. Check the volume is set to the desired level (see page 53 for details)

**Zones****One or more zones show an alarm**

- Check that the zone is wired correctly (see page 21 for wiring details)

**Digimodem****The Digimodem will not dial**

- By default the communicator is disabled, check that the communicator is enabled (see page 64 for details)
- Check that the telephone line has been correctly wired to the communicator (see page 25 for wiring details)
- Check that the telephone numbers are programmed correctly (see page 63 for details)
- Check that the account numbers are programmed correctly (see page 63 for details)
- Check that the dial attempts are not programmed as zero (see page 63 for details)
- Check that the reporting options have been programmed correctly (see page 63 for details)

**Digimodem dials but does not communicate**

- Check that the telephone numbers are programmed correctly (see page 63 for details)
- Check that the correct protocol is programmed (see page 63 for details)

**Operation****The system will not allow me to arm**

- Check that there are no outstanding problems (see page 30 for details)
- Check that there are no outstanding alarms that require resetting (see page 30 for details)
- Check that the User code has been programmed to allow arming (see page 75 for details)

**The system will not allow me to disarm**

- Check that the User code has been programmed to allow disarming (see page 75 for details)

## Reset and Service Messages

When the system requires attention because of a potential problem, the display will show one of three service messages. These messages can also be accessed at any time, allowing the user to view installer information.



**NOTE** These messages would normally be programmed with the telephone numbers of the installer or the Alarm Receiving Centre (see page 48 for details).

To display the service messages, proceed as follows:

The display will normally show the time and date:

Tue 06 Mar 2001

Press **(Menu)** followed by **(1)** for the **Service** message:

Call Alarm Co.  
For Service

Press **(Menu)** followed by **(2<sub>acc</sub>)** for the **Reset** message:

Call EnGineer to  
Reset System

Press **(Menu)** followed by **(3<sub>ser</sub>)** for the **Anti-code** message:

Call ARC to  
Reset System

Press **(Reset)** to exit from the message, the display will then return to normal.

When alarm information is being displayed, pressing the SCROLL key will slow down the display and also allow manual scrolling through the events.

## Fault Warning Tones

When a fault condition occurs i.e. mains fail, line fault etc. the internal sounders will chime every 30 seconds for 3 minutes. The chiming will automatically stop when a valid User code is entered, when **(Reset)** is pressed or after 3 minutes (whichever occurs first). The fault indication will only be cleared from the display when the fault has been rectified i.e. power, telephone line has been restored.

## Other Messages

Alarm EnGineer  
Workin9 On Site

The alarm engineer has logged into the programming menu and is working on site (this message will clear when the engineer logs off or the system is armed).

Confirm Devices  
Tue 06 Mar 2001

The number of devices connected to the networks has changed from the last time a 'Confirm Devices' was done.

Remote Keypad is  
now LOCKED out

To many invalid code attempts have caused the keypad to lock out. The keypad will remain like this for 5 minutes.

You need a user  
to enable access

Engineer access has been programmed for Engineer code + User code (see page 44 for details).

## Fault Messages

Service Required  
Tue 06 Mar 2001

The service timer has expired indicating that the system requires a service, zones that have been placed on test have failed the test or a fault has occurred that requires attention (the system can normally still be used). Contact your alarm company to advise.

Mains Power Off  
Tue 06 Mar 2001

There is a Mains failure (the keypad may chime every minute, enter a valid code to stop the chime). The display will automatically clear when mains is reapplied.

Phone Line Fault  
Tue 06 Mar 2001

There is a Phone Line fault (the keypad may chime every minute, enter a valid code to stop the chime). The display will automatically clear when line fault clears.

\* NO BATTERY \*  
Tue 06 Mar 2001

The Standby Battery has not been connected, the display will automatically clear after 1 minute.

Battery Fault  
Tue 06 Mar 2001

There is a fault with the control panel standby battery.

Panel Lid Tamper  
Tue 06 Mar 2001

There is a fault with the control panel lid tamper.

Bell Tamper  
Tue 06 Mar 2001

There is a fault with the bell tamper on the control panel.

Auxiliary Tamper  
Tue 06 Mar 2001

There is a fault with the auxiliary tamper on the control panel.

Bell Fuse Blown  
Tue 06 Mar 2001

The bell/Strobe PTC has failed

Aux. Fuse Blown  
Tue 06 Mar 2001

The 12V Auxiliary PTC has failed

RKP X Tamper  
Tue 06 Mar 2001

There is a fault with the lid tamper of Keypad X.

RKP X Lost  
Tue 06 Mar 2001

Keypad X has been lost off of the system.

EXP X Tamper  
Tue 06 Mar 2001

There is a fault with the lid tamper of Expander X

EXP X Lost  
Tue 06 Mar 2001

Expander X has been lost off of the system.

EXP X Lo Volts  
Tue 06 Mar 2001

The voltage at expander X is very low.

EXP Bell Tamp X  
Tue 06 Mar 2001

The expander's Bell input (that is programmed as bell tamper) is in fault.

EXP Aux Tamp X  
Tue 06 Mar 2001

The expander's Auxiliary input (that is programmed as aux tamper) is in fault.

## 5. Programming the Control Panel

### Introduction

All engineers should read this section carefully so as to familiarise themselves with the programming of the control panel.

To access the Programming menu, **enter the factory default Engineer code** (1) (2 abc) (3 def) (4 ghi).

If a mistake is made whilst entering the Engineer code, simply re-enter the correct code.

### WARNING

**When an Engineers code is entered to gain access to the Programming menu, by default ALL zones and tampers are disabled.**

**The Strobe output will also pulse 3 times, invoking Engineers Hold Off mode if a Texecom bell box is connected.**

A menu option can then be selected by pressing one of the keys shown or by using the (◀▶) key to search. Once selected, **press YES** to access that option.


To leave the selected menu option and return to the main programming menu, **press** (Reset).

To exit from the Main Programming menu but still remain 'Logged' onto the system (zones and tampers still disabled), **press** (Reset) and the display will show 'Alarm Engineer Working On Site'.

To log the Engineer off the system, **press** (0) followed by **YES** and the system will revert to its normal condition.

The table below shows the menu options available:

Key	Menu Option	Page
(1)	Zone Setup	34
(2 abc)	Arming Options	39
(3 def)	Global Options	43
(4 ghi)	Keypad Setup	50
(5 jkl)	Expander Setup	52
(6 mno)	System Outputs	53
(7 pqrs)	UDL/Digi Options	60
(8 tuv)	Setup Users	72
(9 wxyz)	Engineer Utils	77
(Part)	Alter Part Arms	84
(Menu)	The Arming Menu	-
(0)	Log Off Engineer	33
(Reset)	Exit programming mode	33




## Programming Menu Guide

Key	Main Menu	Key	Sub Menu
<b>1</b>	Zone Setup	<b>Yes</b> <b>Yes</b> <b>Yes</b> <b>Yes</b> <b>Yes</b>	Zone Types Zone Attributes 1 Zone Attributes 2 Zone Text Zone Wiring
<b>2<sub>abc</sub></b>	Arming Options	<b>0<sub>...</sub></b> <b>1</b> <b>5<sub>kl</sub></b>	Timers Arming Modes Options
<b>3<sub>def</sub></b>	Global Options	<b>0<sub>...</sub></b> <b>1</b> <b>2<sub>abc</sub></b> <b>4<sub>ghi</sub></b> <b>5<sub>kl</sub></b> <b>8<sub>uv</sub></b>	System Timers System Config. System Options Control Timers System Text Speaker Tones
<b>4<sub>ghi</sub></b>	Keypad Setup	<b>Yes</b> <b>Yes</b> <b>Yes</b> <b>Yes</b>	Zone Mapping Options Speaker Volume Sounder Options
<b>5<sub>kl</sub></b>	Expander Setup	<b>Yes</b> <b>Yes</b> <b>Yes</b>	Auxiliary Input Speaker Volume Sounder Options
<b>6<sub>mno</sub></b>	System Outputs	<b>0<sub>...</sub></b> <b>1</b> <b>2<sub>abc</sub></b> <b>4<sub>ghi</sub></b> <b>5<sub>kl</sub></b>	Panel Outputs Com? Channels PGM Outputs Keypad Outputs Expander Outputs
<b>7<sub>pqrs</sub></b>	UDL/Digi Options	<b>0<sub>...</sub></b> <b>1</b> <b>3<sub>def</sub></b> <b>4<sub>ghi</sub></b> <b>5<sub>kl</sub></b> <b>7<sub>pqrs</sub></b> <b>8<sub>uv</sub></b>	Reset Digi Test Com? Program Digi Digi Options UDL Options Radio/SMS Options Com Port Setup
<b>8<sub>uv</sub></b>	Setup Users	<b>Yes</b> <b>Yes</b> <b>Yes</b> <b>Yes</b> <b>Yes</b>	User Code User Type User Options User Text Program TAG
<b>9<sub>wxyz</sub></b>	Engineer Utils	<b>0<sub>...</sub></b> <b>1</b> <b>2<sub>abc</sub></b> <b>3<sub>def</sub></b> <b>4<sub>ghi</sub></b> <b>5<sub>kl</sub></b> <b>6<sub>mno</sub></b> <b>7<sub>pqrs</sub></b> <b>8<sub>uv</sub></b> <b>9<sub>wxyz</sub></b> <b>↕</b>	View Event Log Do Bell Test Do Walk Test View Zone Status System Tests Confirm Devices View RKP Status View Exp. Status Set System Time Set System Date Change Eng. Code













Key	Main Menu	Key	Sub Menu
<b>Part</b>	Part Arms	<b>Omit</b> <b>Chime</b> <b>Part</b>	Part Arm 1 Part Arm 2 Part Arm 3
<b>Menu</b>	Arming Menu	<b>0<sub>...</sub></b> <b>1</b> <b>2<sub>abc</sub></b> <b>Omit</b> <b>Chime</b> <b>5<sub>kl</sub></b>	Exit Menu Arm System Part Arm System Omit Zones Set Chime Use Anti-code
<b>Menu</b>	User Menu	<b>0<sub>...</sub></b> <b>1</b> <b>2<sub>abc</sub></b> <b>Chime</b> <b>4<sub>ghi</sub></b> <b>5<sub>kl</sub></b> <b>6<sub>mno</sub></b> <b>7<sub>pqrs</sub></b> <b>8<sub>uv</sub></b> <b>9<sub>wxyz</sub></b> <b>Part</b> <b>↕</b> <b>↕</b>	Exit Menu View Event Log Change Code Edit Chime Zones Bell Tests Walk Test Enable Engineer Set System Time Set System Date Setup Users Alter Part Arms Call Remote PC Edit Phone No's
<b>Reset</b>	Exit programming menu (engineer still logged on)		
<b>0<sub>...</sub></b>	Log Off Engineer		




## Programming Text

Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press  to move the cursor along).

The table below shows the keys to use and the characters that are assigned to them:

Key	Character															
	-	0														
	.	,	?	!	1	@	"	-	&	%	/	+	=	\$	:	;
	A	B	C	2	a	b	c									
	D	E	F	3	d	e	f									
	G	H	I	4	g	h	i									
	J	K	L	5	j	k	l									
	M	N	O	6	m	n	o									
	P	Q	R	7	p	q	r	s								
	T	U	V	8	t	u	v									
	W	X	Y	9	w	x	y	z								
	Move Cursor															
	Backspace (delete)															





## Log Off Engineer

Whenever the Engineer Programming menu is exited by pressing  twice, the display will look like this:



Alarm Engineer  
Working On Site. Tue 06 Mar 2001

This message will stay on the display until the Engineer logs off.


 To log off, proceed as follows:

**Enter an Engineer code**    , the display should look like this:

YES to Select:-  
Zone Setup

**Press**  or , the display should look like this:

YES to Select:-  
Lo9 off ENGINEER

**Press**  to return to normal, the display will look something like this:





Tue 06 Mar 2001

The Engineer is now logged out of the Programming menu.



The Engineer will automatically be logged out 1 hour after the last key press.

## Reset the Engineers Code (User 00)

If the Engineer code (User 00) has been lost or forgotten, it can normally be reset back to the factory default of    . However, this can only be done if the NVM has not been locked (see page 44 for details).

To Reset the Engineer code (User 00):

### ENSURE THAT THE LID TAMPER IS OPEN


**Short** out the 'Load Default' pins for 5 seconds (with the control panel still powered), after 5 seconds, the sounders/keypads will bleep to indicate that the Engineer code has been reset.



NO other codes/programming will be affected, it is just the User 00 Engineer code that will be reset.

The Engineer (User 00) code can only be reset, if the NVM has not been locked (see page 44 for details).

## 5.1 Zone Setup



## Zone Types

Each zone must be programmed before it is recognised by the system.

Zone numbers are entered as a two digit number i.e. Zone 1 would be entered as 01. Each zone consists of a zone type, attributes, zone text and wiring type.

When programming zones, first select a zone type then select any required attributes, program any required zone text and then select the wiring type.

Zone Type + Zone Attributes 1 + Zone Attributes 2 + Zone Text + Wiring Type = Zone Programmed.

The following zone types are available:

### 0 - Not used

A zone that is not monitored by the system, unused zones should be programmed as 'Not Used' or linked out.

### 1 - Entry/Exit 1

Normally used for the main entry/exit door i.e. Front Door. The zone can be activated during the exit mode without causing a 'Fault'. Once the system is armed, activation of the zone will start the 'Entry 1 Delay' timer.



If an Entry/Exit 1 or 2 zone type is omitted, 'Guard Access' zones will automatically become 'Entry/Exit 1' zones to allow access into the premises without causing an alarm.

### 2 - Entry/Exit 2

Normally used for another entry/exit door that requires a different entry delay i.e. Back Door, Garage Door etc. The zone can be activated during the exit mode without causing a 'Fault'. Once the system is armed, activation of the zone will start the 'Entry 2 Delay' timer.

### 3 - Guard

Normally used for detection devices such as PIR's, Door Contacts etc. This zone type will cause an Intruder alarm if it is activated when the system is armed. This zone type will also activate any output programmed as 'Guard Alarm'.

### 4 - Guard Access

Normally used for detection devices along the entry/exit route. This zone type will allow the user to walk past the detector without causing a 'Fault' during the exit mode or an Intruder alarm during the entry mode, however, the zone will cause an immediate Intruder alarm if activated at any other time. This zone type will also start the entry mode when the system is part armed and activate any output programmed as 'Guard Access Alarm'.

### 5 - 24Hr Audible

This zone type will cause an internal alarm if it is activated when the system is disarmed and will cause an Intruder alarm when the system is armed. The panel will also report a '24-Hour' alarm to the Alarm Receiving Centre when using 'Contact ID' reporting.

### 6 - Trouble

When the system is disarmed, a Trouble zone will show on the display when activated and the display will clear when the zone returns to healthy without the need for a code to be entered. However, when the zone is active it will prevent the alarm from being armed. When the system is armed, the zone will not cause any type of alarm.

### 7 - PA Audible

Normally used for monitoring Panic or hold-up alarms. This zone type will cause a Panic alarm if it is activated when the system is armed or disarmed.

### 8 - PA Silent

Normally used for monitoring Panic or hold-up alarms. This zone type will cause a silent Panic alarm if it is activated when the system is armed or disarmed.

### 9 - Fire

Normally used for monitoring smoke detectors. This zone type will cause a Fire alarm with distinctive fire tone if it is activated when the system is armed or disarmed. In addition, the bell output will pulse.

### 10 - 24Hr Gas

This zone type will cause an Audible alarm if it is activated when the system is armed or disarmed. The panel will also report a 24-Hour Gas alarm to the Alarm Receiving Centre when using 'Contact ID' reporting.

### 10 - Auxiliary

This zone type will cause a Silent alarm if it is activated when the system is armed or disarmed. The panel will also report an Auxiliary alarm to the Alarm Receiving Centre when using 'Contact ID' reporting.

### 11 - Tamper

This zone type will cause an Internal alarm if it is activated when the system is disarmed and will cause an Intruder alarm when the system is armed.

### 13 - Exit Terminator

This zone type is used to finalise the arming procedure when arming the system (see page 40 for details).

### 14 - Key Switch

This zone type can be used to arm and disarm the alarm system. When the zone is activated and then secured the system will arm. When the zone is subsequently activated and then secured the system will disarm. Tamper faults will not arm or disarm anything, but will cause a Tamper alarm.

## Zone Attributes 1

Attributes can be assigned to a zone to alter its operation i.e. a Guard zone with the 'Access' attribute will allow the user to walk past the detector without causing a 'Fault' during the exit mode or an Intruder alarm during the entry mode.

Select attributes by pressing keys 1 to 8 (a letter on the display means the attribute is selected, a star on the display means the attribute is not selected).

The following attributes are available:

### **O - Omittable**

Zones with this attribute can be manually omitted.

Zones without this attribute cannot be manually omitted.

### **F - Force Omit**

Zones with this attribute will be omitted if they are not secure at the end of the exit mode.

Zones without this attribute will cause an 'Arm Fail' if they are not secure at the end of the exit mode.

### **1 - Part 1 Omit**

Zones with this attribute will be omitted when 'Part Arm 1' is selected. Keyswitch zones with this attribute will perform a 'Part Arm 1'.

Zones without this attribute will not be omitted when 'Part Arm 1' is selected.

### **2 - Part 2 Omit**

Zones with this attribute will be omitted when 'Part Arm 2' is selected. Keyswitch zones with this attribute will perform a 'Part Arm 2'.

Zones without this attribute will not be omitted when 'Part Arm 2' is selected.

### **3 - Part 3 Omit**

Zones with this attribute will be omitted when 'Part Arm 3' is selected. Keyswitch zones with this attribute will perform a 'Part Arm 3'.

Zones without this attribute will not be omitted when 'Part Arm 3' is selected.

### **1 - Chime 1**

Zones with this attribute will cause the internal sounders to generate a single Chime tone when activated.

### **2 - Chime 2**

Zones with this attribute will cause the internal sounders to generate a double Chime tone when activated.

### **G - Guard**

Entry/Exit 1 or 2 or Guard Access Zones with this attribute will cause an Intruder alarm when the system is part armed.

Guard Zones with this attribute will become Entry/Exit 2 when the system is part armed.

Zones without this attribute will respond as normal.

## Zone Attributes 2

Select attributes by pressing keys 1 to 8 (a letter on the display means the attribute is selected, a star on the display means the attribute is not selected).

The following attributes are available:

### **D - Double Knock**

Zones with this attribute will only cause an alarm if it is activated twice within the 'Double Knock' time window or for the duration of the time window.

Zones without this attribute will respond as normal.

### **S - Shunt Group**

Zones with this attribute will be isolated whenever a 'Shunt' code is entered or a 'Shunt' keyswitch is operated and will be reinstated when the code or keyswitch is used again.

Zones without this attribute will respond as normal.

### **T - On Soak Test**

Zones with this attribute will not cause an alarm if activated during the 'Soak Test Time' (see page 43 for details). However, the system will record the event in the log and indicate to the user that the zone has failed the test. A test failure will NOT prevent the user from arming and will clear when an Engineer code is entered.

Zones without this attribute will respond as normal.

### **A - Activity**

Zones with this attribute will cause an activity fault to be displayed at the time of arming if they have not been activated during the 'Activity Delay' period. If 'Config. option 14' (see page 44 for details) has been set to 'Activity Fault Bar' the system cannot be armed until the zone has been activated (forced walk test).

Zones without this attribute will respond as normal.

### **R - Reset**

Zones with this attribute will not be monitored during the 'Detector Reset' period i.e. when the exit mode is started and power is removed from certain detectors (to reset them) the 'Fault' on the zone is ignored.

Zones without this attribute will be monitored as normal.

### **I - Inverted**

Zones with this attribute will report their 'Secure' and 'Active' status the opposite way round. 'Tampers' always respond as normal.

Zones without this attribute will respond as normal.

### **Q - Quick Resp.**

The response time of zones with this attribute is governed by the 'Zone Loop' response Timer (see page 43 for details).

The response time of the zone is fixed at 250mS.

### **! - Shock**

Zones with this attribute will cause any 'Entry/Exit 1' zone type to automatically become a 'Guard' zone for 10 seconds.

Zones without this attribute will respond as normal.

## Attributes for Moment or Latch Keys

Select attributes by pressing keys 1 to 8 (a letter on the display means the attribute is selected, a star on the display means the attribute is not selected).

The following attributes are available for Keyswitch zones:

### I - Instant Arm

The system will arm instantly instead of using the exit timer.

### S - Shunt Key

When the zone is 'Active', any zone with the 'Shunt' attribute will be isolated until the zone returns to 'Secure'.

### F - Full Disable

When using a key switch to 'Full' arm the system, the key switch is disabled once it is armed.

### P - Disarm Only

The keyswitch can only be used to disarm the system.

### F - Silent Arming

When using a keyswitch to arm, the system will arm silently.

### I - Inverted

The operation of the keyswitch is inverted.


### Q - Quick Resp.

The response time of the zones with this attribute is governed by the 'Zone Loop' response Timer













### L - Latching

When the keyswitch is 'Active', the system will arm. When the zone is 'Secure', the system will disarm.

## Zone Text

Each zone can have up to 16 characters of descriptive text assigned to it. Text is programmed in a similar way to mobile phones. Select characters by pressing the corresponding key the appropriate number of times (to select a character on the same key, press  to move the cursor along).

The table below shows the keys to use and the characters that are assigned to them:

Key	Character															
	_	0														
	.	,	?	!	1	@	"	-	&	%	/	+	=	\$	:	;
	A	B	C	2	a	b	c									
	D	E	F	3	d	e	f									
	G	H	I	4	g	h	i									
	J	K	L	5	j	k	l									
	M	N	O	6	m	n	o									
	P	Q	R	7	p	q	r	s								
	T	U	V	8	t	u	v									
	W	X	Y	9	w	x	y	z								
	Move Cursor															
	Backspace (delete)															

## Zone Wiring Type

The following wiring configurations are available for each zone on the system. For wiring details please see page 21.

### 0 - Normally Closed

For use on normally closed devices without tamper protection. Normally used for keyswitches. See **Normally Closed** wiring diagram on page 21

### 1 - Normally Open

For use on normally closed devices without tamper protection. Normally used for keyswitches. See **Normally Open** wiring diagram on page 21.

### 2 - Double Pole/EOL

Default zone wiring configuration as shown on page 21.

### 3 iD

This option must be selected when wiring iD zones using an **24iXD** expander.

### 4 - Triple EOL

Standard Texecom TEOL as illustrated on page 21, use this wiring type for all Texecom anti masking detectors.

### 5 - 1K/1K/3K

Alternative TEOL configuration with 1K alarm resistor, 3K fault resistor and 1K EOL resistor

### 6 - 4K7/6k8/12K

Alternative TEOL configuration with 6K8 alarm resistor, 12K fault resistor and 4K7 EOL resistor.

### 7 - 2K2/4K7/6k8

Alternative TEOL configuration with 4K7 alarm resistor, 6K8 fault resistor and 2K2 EOL resistor

### 8 - 4K7/4k7

Alternative EOL configuration with 4K7 alarm resistor and 4K7 EOL resistor.

## DD 243:2002

To comply with DD 243:2002, during the normal entry delay, the control panel must prevent a Confirmed Intruder Alarm from being reported to the Alarm Receiving Centre.


If a Portable ACE i.e. Electronic Keyswitch, Key Fob, Tag, Swipe Card etc. is being used for disarming, it is permissible for the Confirmed Intruder Alarm signal to be re-enabled after the entry delay has expired.

### **WARNING**

**Owing to the ability to disable ALL of the confirmation facilities, the customer should be advised in writing by the alarm company that ALL means of alarm confirmation are disabled when the initial entry door is opened. The alarm company should then obtain written acceptance from the customer of the disabling of the means of alarm confirmation.**

## 5.2 Arming Options

### Timers



There are 8 timers that control timing and delay functions. Each timer can be programmed for any value between 000 and 255.

#### 1 - Exit Delay

When the exit mode is programmed as 'Timed' this timer controls the delay between the user initiating the exit mode for the system actually arming (Default = 030 Seconds).

#### 2 - Entry 1 Delay

If the system is armed and an 'Entry/Exit 1' zone is activated, this timer will start and the entry tone will be heard. If the system is not disarmed before this timer expires, the '2<sup>nd</sup> Entry Delay' timer will start. (Default = 015 Seconds).

#### 3 - Entry 2 Delay

If the system is armed and an 'Entry/Exit 2' zone is activated, this timer will start and the entry tone will be heard. If the system is not disarmed before this timer expires, the '2<sup>nd</sup> Entry Delay' timer will start. (Default = 030 Seconds).

#### 4 - 2<sup>nd</sup> Entry Delay

When the 'Entry Delay 1 or 2' timer expires, this timer will start and an Internal alarm will occur. If the system is still not disarmed before this timer expires, an Intruder alarm will then occur (Default = 000 Seconds).

#### 5 - Bell Delay

This timer controls the delay between an Intruder alarm occurring and the 'Bell/Strobe' output activating (Default = 000 Minutes).

#### 6 - Bell Duration

This timer controls the duration of the 'Bell' output after an Intruder alarm has occurred and any programmed 'Bell Delay' has expired (Default = 015 Minutes).


#### 7 - Coms Delay

This timer controls the delay between an Intruder alarm occurring and the communicator reporting to the Alarm Receiving Centre (Default = 000 Seconds).

#### 8 - Part Bell Delay

When the system is 'Part Armed' this timer controls the delay between an Intruder alarm occurring and the 'Bell/Strobe' output activating, the internal sounders will also sound during this time as a warning (Default = 000 Minutes).

## Arming Modes



The way that an the system arms can be configured for any of the following options:

### 1 - Entry/Exit

The system will arm after the 'Entry/Exit' door has been closed and the 'Exit Settle' timer has expired.

### 2 - Exit Term.

The system will arm after the 'Entry/Exit' door has been closed, the 'Exit Terminator' button has been pressed and the 'Exit Settle' timer has expired.

### 3 - Timed Exit

The system will arm after the programmed 'Exit Time' has expired.



**NOTE** If an 'Exit Terminator' zone is activated at any point during the exit mode, any remaining exit time is cancelled and the system will arm immediately.


### 4 - Instant

The system will arm instantly.

### 5 - Deferred

The system will arm after the programmed 'Exit Time' has expired. However, if any zones not on the exit route are activated during the exit mode, the 'Exit Time' is restarted.

## Options



There are 21 options that control how various features affect the alarm.



## Options 1

### **A - Auto Part Arm (Default = Disabled)**

The system will fully arm if an 'Entry/Exit' zone is activated during the exit mode and will 'Part Arm 1' if an 'Entry/Exit' zone is not activated during the exit mode.



NOTE To activate an Entry/Exit zone for this facility it is sufficient for the zone to switch from active to healthy (closing of the door only).

### **S - Part Arm Silent (Default = Disabled)**

The system will always Part Arm silently.

### **R - Remote Arm/Disarm (Default = Enabled)**

The system can be armed and disarmed remotely using the *Wintex UDL* software and a Digicom or *ComGSM*.

### **T - Time Arm CT1 (Default = Disabled)**

The system will automatically arm using Control timer 1.

### **E - Alarms Eng Reset (Default = Disabled)**

The system can be programmed for Engineer or User reset following an Intruder alarm, if programmed as 'Alms Eng Reset' the system will respond as follows:

A normal Intruder alarm can only be reset using an Engineer code

If 'Anti-code Reset' is enabled (option A) the system can also be reset using the Anti-code

### **C - Confirmed Reset (Default = Enabled)**

The system can be programmed for Engineer or User reset following a Confirmed alarm, if programmed as 'Confirmed Reset' the system will respond as follows:

A confirmed Alarm can only be reset using an Engineer code

If 'Anti-code Reset' is enabled (option A) the system can also be reset using the Anti-code

### **T - Tamper Eng Reset (Default = Enabled)**

The system can be programmed for Engineer or User reset following a Tamper alarm (when the system is unarmed), if programmed as 'Tamper Eng Reset' the system will respond as follows:

A Tamper Alarm can only be reset using an Engineer code

If 'Anti-code Reset' is enabled (option A) the assigned areas can also be reset using the Anti-code

### **A - Anti-code Reset (Default = Enabled)**

The system can be programmed for Anti-code Reset following an Intruder or Tamper alarm, if programmed as 'Anticode Reset' the system will respond as follows:

An Alarm condition can be reset using the Anti-code as well as an Engineer code



NOTE The system can only be programmed for 'Anti-code Reset' if it is also programmed as 'Alarms Eng Reset'.

## Options 2

### **L - Arm With L/Fault (Default = Enabled)**

The system can be armed with a line fault present.

### **A - Arm with AC Fail (Default = Enabled)**

The system can be armed with a mains fault present.

### **P - Part Arm Coms (Default = Disabled)**

When 'Part Arm Coms' is enabled the system will respond as follows:

When the system is part armed and an Intruder alarm occurs, Intruder alarm events are reported to the Alarm Receiving Centre after any programmed 'Coms Delay' has expired

### **F - Unarm Fire Coms (Default = Disabled)**

When 'Unarm Fire Coms' is enabled, Fire alarm events will be reported to the Alarm Receiving Centre whilst the system is disarmed



NOTE Fire alarm events are always reported to the Alarm Receiving Centre when the system is armed regardless of whether this option is enabled or not.

### **T - Unarm Tamp. Coms (Default = Disabled)**

When 'Unarm Tamp Coms' is enabled, 24Hr and Tamper alarm events (for that area) will be reported to the Alarm Receiving Centre whilst the system is disarmed



NOTE 24Hr and Tamper alarm events are always reported to the Alarm Receiving Centre when the system is armed regardless of whether this option is enabled or not.

### **L - Log Part Omits (Default = Disabled)**

When enabled, zones that have been omitted during a part arm are logged in the event log.

### **I Confirm in Entry (Default = Disabled)**

When 'Confirm in Entry' is enabled the system will respond as follows:

Once the entry timer is started if two or more zones are activated a Confirmed alarm will occur, and will be reported to the Alarm Receiving Centre



NOTE To comply with DD 243:2002, this option must NEVER be enabled, thus preventing Confirmed Alarms from being reported to the Alarm Receiving Centre during the entry mode.

### **A - Conf. after Entry (Default = Disabled)**

When 'Conf. After Entry' is enabled the system will respond as follows:

Once the entry timer expires if two or more zones (not on the entry route) are activated a Confirmed alarm will occur, and will be reported to the Alarm Receiving Centre



NOTE If a Portable ACE i.e. Electronic Keyswitch, Key fob, Tag, Swipe Card etc. is used to disarm the system, it is permissible for the Confirmed Intruder Alarm signal to be re-enabled after the entry delay has expired. In this case, this option CAN be enabled.

## Options 3

### **F – Faults Eng Reset (Default = Disabled)**

The system can be programmed for Engineer or User reset following any Fault with exception to “No ATS Available” and “AC Fail”. If programmed as ‘Faults Eng Reset’ the system will respond as follows:

All System Faults (except No ATS Available and AC Fail) can only be reset using an Engineer code or “Anti-code Reset” (if enabled).

### **A – No ATS Eng Reset (Default = Disabled)**

The system can be programmed for Engineer or User reset following a “No ATS Available” fault (ATS = Alarm Transmission System). If programmed as “No ATS Eng Reset” the system will respond as follows:

The No ATS Available fault can only be reset using an Engineer code or “Anti-code Reset” (if enabled).

### **A – AC Fail Eng Reset (Default = Disabled)**

The system can be programmed for Engineer or User reset following an AC Mains Fail. If programmed as ‘AC Fail Eng Reset’ the system will respond as follows:

The AC Mains Fail fault can only be reset using an Engineer code or “Anti-code Reset” (if enabled).

### **M – Mask When Armed (Default = Disabled)**

When ‘Mask When Armed’ is enabled the zone will register a masking fault if the system is armed and a masking fault occurs.

When disabled, the zone will never register a Masking fault when the system is armed and a Masking Fault occurs.



NOTE

The way the system responds to a Masking fault is determined by System Config option 26 (see page 46).

### **F – FOB After Entry (Default = Disabled)**

When ‘FOB After Entry’ is enabled the system can only be disarmed with a Radio FOB once the Entry procedure has been started.

When disabled, the system can be disarmed with a Radio FOB at any time.

## DD 243:2002 Options

To comply with DD 243:2002, during the normal entry delay, the control panel must prevent a Confirmed Intruder Alarm from being reported to the Alarm Receiving Centre.

If a Portable ACE i.e. Electronic Keyswitch, Key Fob, Tag, Swipe Card etc is being used for disarming, it is permissible for the Confirmed Intruder Alarm signal to be re-enabled after the entry delay has expired.


The previous two options have been provided to ensure that the control panel can be programmed to comply with this standard if required.

## WARNING

**Owing to the ability to disable ALL of the confirmation facilities, the customer should be advised in writing by the alarm company that ALL means of alarm confirmation are disabled when the initial entry door is opened. The alarm company should then obtain written acceptance from the customer of the disabling of the means of alarm confirmation.**

## 5.3 Global Options

### System Timers



There are 15 global timers that control system timing and delay functions. Each timer can be programmed for any value between 000 and 999.

#### 1 - Exit Settle Time

When using the 'Entry/Exit' or 'Exit Terminator' arming mode, some detectors along the exit route can remain active for a number of seconds following activation. This timer ensures that the detectors are given time to deactivate before the system arms. (Default = 008 Seconds).

#### 2 - Double Knock Dly

If a zone has the 'Double Knock' attribute an alarm will only occur if the zone activates twice within this time window or once for the duration of this time window. (Default = 030 Seconds).

#### 3 - Activity Delay

If a zone has the 'Activity' attribute and it is not activated during this timer and 'Config. option 14' has been set to 'View Act. Fault' (see page 44 for details), it will be indicated to the user when they try to arm the system. (Default = 024 Hours).

#### 4 - Abort Delay

When an Intruder alarm occurs this timer is started, if the system is disarmed within this time window an 'Abort' event will be reported to the Alarm Receiving Centre. If the system is disarmed after this period the 'Abort' event is not reported. (Default = 180 Seconds).

#### 5 - Courtesy Time

This timer controls the duration of the 'Courtesy' output type. The courtesy output activates whenever a keypad is being used and during the entry mode. (Default = 060 Seconds).

#### 6 - Pulse Period 1

This timer controls how long any output with the 'Pulse Period 1' attribute assigned to it will activate for. (Default = 010 Seconds).

#### 7 - Line Fault Delay

This timer controls the delay between a line fault occurring and an audible indication being generated by the system. (Default = 030 Minutes).

#### 8 - AC Off Delay

This timer controls the delay between an AC Mains failure occurring and an audible indication being generated by the system. (Default = 030 Minutes).

#### 9 - Batt Test Period

This timer controls the frequency of the dynamic battery test. (Default = 024 Hours).

#### 10 - Batt Test Time

This timer controls how long the dynamic battery test is carried out for. (Default = 060 Seconds).

#### 11 - Soak Test Time

This timer controls the number of days a zone with the 'Test' attribute will remain on test for. (Default = 014 Days).

#### 12 - Service Interval

This timer controls the frequency of the 'Service Required' condition occurring. (Default = 000 Weeks).

#### 13 - Test Call Every

This timer controls how often a test call is made to the monitoring station. 024 = daily etc. (Default = 000 Hours).


#### 14 - Zone Response

This timer controls the length of time that a zone with the 'Quick Response' attribute, has to be activated for, in order to be recognised by the control panel. (Default = 075x10mSeconds).

#### 15 - Confirmation Dly

When an Intruder alarm occurs, this timer starts. If a second (different) zone is activated within this time window, the 'Confirmed' output will activate. When this timer expires, the 'Confirmed' output will no longer activate. (Default = 045 Minutes).

## System Config.



These options control how various system functions work.

### 00 - No Bell Arm Fail (Default)

If the system fails to arm, an Internal alarm will occur and the 'Strobe' output will activate.

#### Bell on Arm Fail

If the system fails to arm, an Internal alarm will occur and the 'Bell' output will activate for 10 seconds.



The 'Strobe' output will also activate for 5 seconds to indicate that the system has armed and disarmed successfully.

### 01 - Bell is an SAB (Default)

The 'Bell' output on the control panel applies 0V when it activates.

#### Bell is an SCB

The 'Bell' output on the control panel removes 0V when it activates.

### 02 - Manual BST/GMT

The system clock will not adjust itself at the beginning and the end of the summer (the clock will have to be adjusted manually).

#### Auto BST/GMT (Default)

The system clock will adjust itself at the beginning and the end of the summer (the clock will automatically gain 1Hr on the last Sunday in March and lose 1Hr on the last Sunday in October).

### 03 - Leave Omits

When zones have been 'Omitted' by a user, the zones will remain omitted until the user reinstates them.

#### Remove Omits (Default)

When zones have been 'Omitted' by a user, the zones will be automatically reinstated when the system is disarmed.

### 04 - Override Com Dly (Default)

If the system is 'Fully' armed and an Intruder alarm occurs, Intruder alarm events are reported to the Alarm Receiving Centre immediately.

#### Enforce Com Dly

If the system is 'Fully' armed and an Intruder alarm occurs, Intruder alarm events are reported to the Alarm Receiving Centre after any programmed 'Coms delay' has expired (see page 39 for details).

### 05 - NVM is Unlocked (Default)

The factory default settings can be reloaded by shorting the load default pins during power up.

#### NVM is Locked

The factory default settings cannot be reloaded by shorting the load default pins during power up.



If the NVM is locked and the Engineer User code has been lost or forgotten, the control panel will have to be returned to Texecom to be unlocked.

### 06 - Engineer Only (Default)

Access to the Engineers Programming menus can be obtained by just entering the Engineer User code.

#### User + Engineer

Access to the Engineers Programming mode can only be obtained, if a User (with the 'Engineer Access' attribute) has authorised engineer access.

### 07 - Omit Tamper No (Default)

A user cannot omit Tamper faults on a zone.

#### Omit Tamper Yes

A user can omit Tamper faults on a zone.

### 08 - 80 Column Print (Default)

Select this option when connecting a 80 Column printer to the control panel.

#### 40 Column Print (Default)

Select this option when connecting a 40 Column printer to the control panel.

### 09 - Hide Act. Fault (Default)

If a zone with the 'Activity' attribute is not activated during the 'Activity Delay' time window, the system can still be armed. However, this fault will be indicated to the user when they try to arm.

#### View Act. Fault

If a zone with the 'Activity' attribute is not activated during the 'Activity Delay' time window, the system cannot be armed. This situation can only be overcome by activating the zone.

**10 - View Zone Faults**

Active zones and their status are always displayed in real time on the keypad when the system is disarmed.

**Hide Zone Faults (Default)**

Active zones and their status are never displayed in real time on the keypad when the system is disarmed.

**11 - Enable Code Tamper (Default)**

24 invalid key presses on a keypad will cause a Code Tamper condition (see option 17).

**No Code Tamper**

A Code Tamper condition will never occur when the keys on a keypad are pressed more than 24 times.

**12 - Code Tamper Alarm (Default)**

A Code Tamper condition will cause a Tamper alarm.

**Code Tamper Lockout**

A Code Tamper condition will cause the keypad to lockout for 5 minutes.

**13 - Short = Active**

The control panel will see a zone that is in the short circuit condition as 'Active'.

**Short = Tamper (Default)**

The control panel will see a zone that is in the short circuit condition as a 'Tamper'.

**14 - R/R=Reset Only (Default)**

When 0V is applied to the control panel R/R input, any outstanding alarms will be reset (see page 41 for details).

**R/R=Silence/RST**

When 0V is applied to the control panel R/R input the internal sounders will be silenced. When 0V is applied to the R/R input a second time, any outstanding alarms will be reset. (this would normally be used when Audio Verification is required).

**15 - Timed Test Call (Default)**

A test call to the Alarm Receiving Centre will occur every time the 'Test Call Every' timer expires.

**Test Call = CT3**

A test call to the Alarm Receiving Centre will occur every time 'Control Timer 3' activates.

**16 - Batt Test Timed (Default)**

A battery test will occur every time the 'Batt Test Period' timer expires.

**Batt Test = Disarm**

A battery test will occur every time the system is disarmed or after the 'Batt Test Period' timer has expired (whichever occurs first).

**17 - Bell = 1st Alarm (Default)**

The 'Bell' and 'Strobe' outputs will activate after an Intruder alarm (1st Alarm) occurs.

**Bell = 2nd Alarm**

The 'Bell' and 'Strobe' outputs will activate after a Confirmed alarm (2nd Alarm) occurs.

**18 - SNDR = 1st Alarm (Default)**

The internal sounders will sound after an Intruder alarm (1st Alarm) occurs.

**SNDR = 2nd Alarm**

The internal sounders will sound after a Confirmed alarm (2nd Alarm) occurs.

**19 - Abort=Eng.Reset (Default)**

An Intruder alarm that is aborted can only be reset by an Engineer/Anti-code.

**Abort=User Reset**

An Intruder alarm that is aborted can be reset by the User.

**20 - 8XE = Zones 9-16 (Default)**

The 8 zones on the 8XE local zone expander will report as zones 9 to 16.

**8XE = Tamperers 1-8**

The 8 zones on the 8XE local zone expander will report as the tamperers for zones 1 to 8.

**21 - 2nd Zone = Confirm (Default)**

After the entry timer has expired, activation of 2 more zones is required to generate a Confirmed alarm

**1st Zone = Confirm**

After the entry timer has expired, activation of 1 more zone is required to generate a Confirmed alarm

**22 - Access No Conf. (Default)**

Zones programmed as 'Guard Access' can never generate a confirmed alarm once the entry timer has started.

**Access = Confirm**

Zones programmed as 'Guard Access' can generate a confirmed alarm once the entry timer has expired.

**23 - EN50131 Disabled (Default)**

The Control Panels EN50131 options are disabled.

**EN50131 Enabled**

The Control Panels EN50131 options are enabled.



This options must be enabled to comply with EN50131

**24 - Panel Grade 2**

All options relating to PD6662: 2004/EN 50131-1 Grade 3 that are not required for Grade 2 systems are disabled automatically. Also, the Premier Anti-code reset becomes the standard 4 digit number and all user and engineer codes can be 4, 5 or 6 digits.

**Panel Grade 3**

All options relating to PD6662: 2004/EN 50131-1 Grade 3 systems are enabled automatically. Also, the Premier Anti-code reset becomes a 6 digit number and all user codes can only be programmed as 5 or 6 digits.

**25 - Disable RF PA(Default)**

When a 'RadioPlus' Transmitter FOB is being used with the alarm system, the Panic Alarm (PA) function i.e. Pressing buttons 1 and 2 together, is disabled.

**Enable RF PA**

When a 'RadioPlus' Transmitter FOB is being used with the alarm system, the Panic Alarm (PA) function i.e. Pressing buttons 1 and 2 together, is enabled.

**26 - Armed Mask = Fault (Default)**

If an Anti-masking signal is detected when the system is armed, the control panel will generate a Fault response.

**Armed Mask=Alarm**

If an Anti-masking signal is detected when the system is armed, the control panel will generate an Alarm response.

**27 - RF PA = Audible (Default)**

PA alarms generated from an RF FOB will cause an audible alarm.

**RF PA = Silent**

PA alarms generated from an RF FOB will cause a silent alarm.


**28 - Dynamic Tests (Default)**

The test call timer will be reset each time the panel makes a successful call. A test call will only be set when the communicator has been inactive for the duration of the test call timer.

**29 -Periodic Tests**

A test call will be sent every time the test call timer expires.  
eg If the timer is set to 24 hours, a test call will be made each day regardless of whether the communicator has been active since the last test call.

## System Options



### 1 - Advisory Volume

Controls the volume of advisory tones (entry/exit etc) from loudspeakers connected to the control panel. 1 = minimum; 8 = maximum. (Default = 5).

### 2 - Chime Volume

Controls the volume level of Chime tones from loudspeakers connected to the control panel. 1 = minimum; 8 = maximum. (Default = 3).

### 3 - No. Of Re-Arms

Controls the number of times that a zone will re-arm. Once the re-arm limit has been reached, the zone is 'Locked Out' and will not cause any further Intruder alarms. (Default = 3).

### 4 - Anti-code Resets

Limits how many Anti-code Resets can be performed by the user. Once the limit has been reached, an Intruder alarm can only be reset using an Engineer code. This counter is cleared every month or whenever an Engineers code is entered.

### 5 - Quick Count


Sets the number of 10mS pulses that are required within 30 Seconds for a zone with the 'Quick Response' attribute to activate.

### 6 - Modem Level

Adjusts the modem attenuation when using a **Com2400**. This can help when sharing a broadband line.

Modem Level	2	1	0	7	6	5	4	3
Attenuation (dB)	+4	+2	0	-2	-4	-6	-8	-10

## Monitor Hardware



The control panel monitors many inputs for fault conditions i.e. the panel lid tamper, bell tamper, aux fuse etc.

Each one of these options can be disabled to overcome problems related to the devices being monitored.

### **P - Phone Line Fault (Default = ON)**

The telephone line is monitored for faults.

### **A - AC Power Failure (Default = ON)**

The AC Mains is monitored for faults.

### **F - Aux Fuse Blown (Default = ON)**

The Auxiliary Fuse/PTC is monitored for faults.

### **B - Bell Tamper (Default = ON)**

The external sounder tamper loop is monitored for faults.

### **A - Aux Tamper (Default = ON)**

The auxiliary tamper loop is monitored for faults.


### **L - Panel Lid Tamper (Default = ON)**

The control panel lid tamper is monitored for faults.

### **B - Battery Faults (Default = OFF)**


The dynamic battery test is enabled.

## Control Timers



There are 4 control timers. Each timer has an ON and OFF time, and can be programmed to operate on any day of the week. Once configured, the timers can be used to arm or disarm the system, lockout users and control outputs.

## System Text



The system has 7 programmable text messages.

### 1 - Reset Message

This 32-character message is displayed whenever the control panel requires an Engineer reset.



NOTE Default = Call Engineer to Reset System.

### 2 - Anti-code Msg.

This 32-character message is displayed whenever the control panel requires an Anti-code Reset.



NOTE Default = Call ARC Centre to Reset System.

### 3 - Service Message

This 32-character message is displayed whenever the control panel requires Daytime reset.



NOTE Default = Call Alarm Co. for Service.

### 4 - Location Text

This 32-character message is displayed whenever the engineer views the location text in 'Engineer Utils'.



NOTE Default = No Location Text Has Been Setup.



**5 - Banner Message**

This 16-character message is displayed above the time and date whenever the control panel is unarmed or fully armed.



NOTE Default = ' ' (Not Defined).

**6 - Part Arm Banner**

This 16-character message is displayed above the time and date whenever the control panel is part armed.



NOTE Default = \* PART ARMED \*

**7 - Printer Header**

This 16-character header will be printed whenever a log printout is taken from the control panel or a Short Message Service (SMS) text message is sent to a mobile phone.



NOTE Default = 'Printer Header'

**8 - Part Arm 1**

This 16-character message is displayed above the time and date whenever the control panel is unarmed or fully armed.



NOTE Default = Evening Arm

**9 - Part Arm 2**

This 16-character message is displayed above the time and date whenever the control panel is unarmed or fully armed.




NOTE Default = Bedtime Arm 1

**10 - Part Arm 3**

This 16-character message is displayed above the time and date whenever the control panel is unarmed or fully armed.



NOTE Default = Bedtime Arm 2

**Speaker Tones**

The speaker output on the control panel can be programmed so that certain types of tones are not generated. When deselected, Fire, Alarms, Fault, Service, Entry, Exit and Chime tones will not be heard.

Select tones by pressing keys 1 to 8 (a letter on the display means the tone is selected, a star on the display means the tone is not selected).

**F - Fire Tones On (Default = ON)**

Fire alarm tones will be generated.

**A - Alarm Tones On (Default = ON)**

Intruder alarm, Tamper alarm and PA alarm tones will be generated.

**F - Fault Tones On (Default = ON)**

Fault tones will be generated.

**S - Service Tone On (Default = ON)**

Service and Warning tones will be generated.

**E - Entry Tones On (Default = ON)**

Entry tones will be generated.


**X - Exit Tones On (Default = ON)**

Exit tones will be generated.

**C - Chime Tones On (Default = ON)**

Chime 1 and 2 tones will be generated.

## 5.4 Keypad Setup



## Keypad Zone Mapping

The zones in the keypad need to be mapped to a valid zone number before they can be used as part of the system i.e. Keypad 1 Zone 1 could be mapped to Zone 5 (panel) and Zone 2 could be mapped to Zone 23 (expander 2) etc.



**NOTE** Until they are mapped, the zones in the keypads will not work and will not be seen by the control panel.

A keypad zone can be mapped to any zone number on the system, however, when mapped to a zone number that already exists i.e. Zone 5 (panel), that zone can no longer be used.

If a zone is mapped to a zone number not already on the system i.e. Zone 23 (expander 2) and expander 2 is then added, that zone on the expander (Zone 23) cannot be used.

If you wish to use the zone on the expander, the keypad zone must be remapped to a different number.

If a zone is remapped to a different number, the new zone number must be treated as a new zone on the system and therefore needs to be programmed accordingly (the zone programming will NOT automatically follow the mapping).

The table below shows the zone allocation when the keypads are installed:

Address	Zones
1 to 8	Not Mapped

## Keypad Options

These 8 options control various keypad functions:

### **P - PA Enabled**

Pressing keys 1 & 3 together will cause a PA alarm.

### **F - Fire Enabled**

Pressing keys 4 & 6 together will cause a Fire alarm.

### **M - Medical Enabled**

Pressing keys 7 & 9 together will cause a Medical alarm.

### **T - Tamper Enabled (Default)**

Removing the keypad cover will cause a Tamper alarm.

### **A - PA Audible**

A keypad PA (1 & 3) will cause an audible PA alarm.

### **D - PA Delayed**

When the keypad PA buttons (1 & 3) are pressed, a 30 second 'Keypad PA Delay' timer starts, if a User code is entered before the timer expires, no PA alarm will occur. If no User code is entered before the timer expires, a PA alarm will occur.

### **Q - Quick Arm is Enabled**

Pressing the Area or Part keys will Arm or Part Arm the alarm without the need to enter a User code first.

### **O - Info.LED> Output**

The 'Info.' LED on the keypad comes on when the keypad output activates and goes off when the keypad output deactivates.

## Keypad Speaker Volume

This option controls the volume level of advisory tones from loudspeakers connected to the keypads. Advisory tones consist of 'Entry/Exit' and 'Warning' type tones. 1 = minimum; 8 = maximum. (Default = 5).



**NOTE** Alarm tones are always full volume.

## Keypad Sounder Options

The sounder and speaker output in the keypad can be programmed so that certain types of tones are not generated. When deselected, Fire, Alarms, Fault, Service, Entry, Exit and Chime tones will not be heard.

Select tones by pressing keys 1 to 8 (a letter on the display means the tone is selected, a star on the display means the tone is not selected).

### **F - Fire Tones On (Default = ON)**

Fire alarm tones will be generated by the keypad sounder/speaker.

### **A - Alarm Tones On (Default = ON)**

Intruder alarm, Tamper alarm and PA alarm tones will be generated by the keypad sounder/speaker.

### **F - Fault Tones On (Default = ON)**

Fault tones will be generated by the keypad sounder/speaker.

### **S - Service Tone On (Default = ON)**

Service and Warning tones will be generated by the keypad sounder/speaker.

### **E - Entry Tones On (Default = ON)**

Entry tones will be generated by the keypad sounder/speaker.


### **X - Exit Tones On (Default = ON)**

Exit tones will be generated by the keypad sounder/speaker.

### **C - Chime Tones On (Default = ON)**

Chime 1, 2 and 3 tones will be generated by the keypad sounder/speaker.

## 5.5 Expander Setup



## Expander Auxiliary Input

Each expander has an input that can be programmed for one of the following options. If not being used, the input must be programmed as 'Not Used' (Default = Not Used).

### **Not Used (Default)**

Never monitored by the system.

### **Aux Tamper**

Normally used for monitoring the box tamper of auxiliary devices such as power supplies etc (remove 0V for Tamper alarm).

### **Bell Tamper**

Normally used for monitoring Bell Tamper returns (remove 0V for Tamper alarm).

### **Silence Sounders**

Normally used to silence the Internal sounders following an Intruder alarm and would be used in conjunction with Audio Verification units (apply 0V to silence).

### **PSU Fault**

Normally used for monitoring an external power supply for faults i.e. mains power off etc (remove 0V for mains fault).

### **Shunt Key**

Normally wired to a key switch. When the input is 'Active' (0V applied), any zone with the 'Shunt' attribute will be isolated until the input returns to 'Secure' (0V removed).

## Expander Speaker Volume

This option controls the volume level of advisory tones from loudspeakers connected to the expanders. Advisory tones consist of 'Entry/Exit' and 'Warning' type tones. 1 = minimum; 8 = maximum (Default = 5).



NOTE

Alarm tones are always full volume.

## Expander Sounder Options

The speaker output on the expander can be programmed so that certain types of tones are not generated. When deselected, Fire, Alarms, Fault, Service, Entry, Exit and Chime tones will not be heard.

Select tones by pressing keys 1 to 8 (a letter on the display means the tone is selected, a star on the display means the tone is not selected).

### **F - Fire Tones On (Default = ON)**

Fire alarm tones will be generated by the expander sounder/speaker.

### **A - Alarm Tones On (Default = ON)**

Intruder alarm, Tamper alarm and PA alarm tones will be generated by the expander sounder/speaker.

### **F - Fault Tones On (Default = ON)**

Fault tones will be generated by the expander sounder/speaker.

### **S - Service Tone On (Default = ON)**

Service and Warning tones will be generated by the expander sounder/speaker.

### **E - Entry Tones On (Default = ON)**

Entry tones will be generated by the expander sounder/speaker.


### **X - Exit Tones On (Default = ON)**

Exit tones will be generated by the expander sounder/speaker.

### **C - Chime Tones On (Default = ON)**

Chime 1, 2 and 3 tones will be generated by the expander sounder/speaker.

## 5.6 System Outputs



## Available Outputs

Various sets of programmable outputs can be found on the control panel, keypads, expanders and output modules.

### Panel Outputs

Panel outputs 1 - 6 are located on the top right hand side of the control panel and can be programmed to any of the output types listed (see page 24 for wiring details).

### Digi Channels

Digi channels 1 - 8 are for the *Com300*, *Com2400* and *ComISDN* plug-on digimodems and can be programmed to any of the output types listed.

### PGM Outputs

PGM output 1 is located along the bottom edge of the control Panel. PGM outputs 2-8 are NOT physical outputs they are 'Software' outputs that can be configured to operate under certain conditions (see page 59 for details). Once configured these outputs can then be assigned to a physical output (see system output 25) or used to restrict code access (see page 75 for details).

### Keypad Outputs

Keypad outputs are for the outputs on the remote keypads (see page 15 for details) and can be programmed to any of the output types listed. Wire as per Panel Outputs shown on page 24.

### Expander Outputs

Expander outputs are for the outputs on the zone/output expanders (see page 18 for details) and can be programmed to any of the output types listed. Wire as per Panel Outputs shown on page 24.

## Programming Outputs

When programming outputs, select an output group and an output type from that group's list (each output group has its own output types) then select attributes (if required).



**NOTE** Output Group + Output Type + Output Attributes = Output Programmed.

## Output Group - Not Used

Only the following output type is available:

### Not Used (off)

This output type never activates.

## Output Group - System

Select an output type from the following options:

### 00 - ATS Path Fault

This output type activates when a fault is detected with the Alarm Transmission System and deactivates when the fault is cleared (Previously 'Phone Line Fault').

### 01 - Mains Power Off

This output type activates when no AC Mains is detected on the control panel and deactivates when mains is detected

### 02 - Aux Fuse Blown

This output type activates when the Auxiliary PTC fails and deactivates when the system is reset.

### 03 - Bell Tamper

This output type activates when the control panel Bell tamper or an expander input (programmed as Bell tamper) is activated, causing a Tamper alarm on the system, and deactivates when the Tamper alarm is reset.

### 04 - Auxiliary Tamper

This output type activates when the control panel Aux tamper or an expander input (programmed as Auxiliary tamper) is activated, causing a Tamper alarm on the system, and deactivates when the Tamper alarm is reset.

### 05 - Panel Lid Tamper

This output type activates whenever the panel cover is removed, causing a Tamper alarm on the system, and deactivates when the Tamper alarm is reset.

### 06 - Engineer Working

This output type activates whenever an Engineer code is entered to access the programming menu and deactivates when the engineer logs off.

### 07 - Confirm Devices

This output type activates when the control panel requires devices to be confirmed and deactivates when the devices are confirmed (see page 80 for details).

### 08 - Service Required

This output type activates when the 'Service Interval' timer expires and deactivates when an Engineer code is entered (see page 43 for details).

### 09 - Shunt Active

This output type activates whenever zones with the 'Shunt' attribute are isolated using either a 'Shunt' code or a 'Shunt' key. And deactivates when the zones are reinstated.

### 10 - Battery Fault

This output type activates when the system detects a fault with the stand-by battery, and deactivates when the fault clears.

### 11 - Battery Test On

This output type activates when the 'Battery Test' starts, and deactivates when the test expires (see page 43 for details).

### 12 - Courtesy Light

This output type activates when the 'Courtesy' timer starts, and deactivates when the timer expires (see page 43 for details).

### 13 - PC Control 1

This output can be activated and deactivated using the *Wintex UDL* software or the *ComGSM* text facility.

### 14 - PC Control 2

This output can be activated and deactivated using the *Wintex UDL* software or the *ComGSM* text facility.

**15 - Coms Failed**

This output type activates when the plug-on digimodem fails to report to the Alarm Receiving Centre (after 3 dialling attempts), and deactivates the next time the digimodem successfully reports to the Alarm Receiving Centre.

**16 - Coms Successful**

This output type activates when the plug-on digimodem successfully reports to the Alarm Receiving Centre and deactivates the next time the digimodem is triggered.

**17 - Coms Active**

This output type activates when the plug-on digimodem is triggered and deactivates when the digimodem shuts down.

**18 - UDL Lockout**

This output type activates when an attempt is made to upload/download with incorrect site details more than three times and deactivates after 4 hours or after a valid User code is entered.

**19 - UDL Call Active**

This output type activates when an upload/download is started and deactivates when the upload/download finishes.

**20 - UDL Enabled**

This output type activates when 'Enable UDL/Engineer' is enabled and deactivates when 'Enable UDL/Engineer' is disabled.

**21 - Custom Output**

This output type activates when 'PGM 5 OR 6 AND 7 AND 8' activate and deactivates when 'any one of the same PGM outputs deactivate (see page 59 for details).

**22 - Activity Fault**

This output type activates whenever a zone with the 'Activity' attribute has not activated and deactivates when the zone activates.

**23 - No Battery**

This output type activates for 1 minute if the engineer logs off the control panel and there is no battery fitted.

**24 - Control Timer 1**

This output type operates when 'Control Timer 1' activates and deactivates when 'Control Timer 1' deactivates.

**25 - Control Timer 2**

This output type operates when 'Control Timer 2' activates and deactivates when 'Control Timer 2' deactivates.

**26 - Control Timer 3**

This output type operates when 'Control Timer 3' activates and deactivates when 'Control Timer 3' deactivates.

**27 - Control Timer 4**

This output type operates when 'Control Timer 4' activates and deactivates when 'Control Timer 4' deactivates.

**28 - Com Port 1 Fault**

This output type activates when whatever is connected to Com Port 1 stops communicating with the control panel and deactivates when communication starts again.

**29 - Com Port 2 Fault**

This output type activates when whatever is connected to Com Port 2 stops communicating with the control panel and deactivates when communication starts again.

**30 - Code Accepted**

This output type activates for 5 seconds whenever a User code is entered.

**31 - Prox TAG Accepted**

This output type activates for 5 seconds whenever a Proximity TAG is presented.

**32 - Radio Jamming**

This output type activates whenever the wireless radio receiver detects a jamming signal and deactivates when the jamming signal is removed.

**33 - Detector Test**

This output type is activated via Wintex to initiate a diagnostics check on an PD6662: 2004/EN 50131-1 Grade 3 detector and deactivates after 10 seconds.

**34 - ATS Remote Test**

This output type conforms to the BSIA Form 175 Specification. When a Line Fault is not present it can be activated remotely by Wintex, or by using the 'Start Test Call' option on the control panel to initiate a test on ATE equipment that have an ATS test input. NOTE: Only the RedCare Line Fault and Control panel Line Fault inputs can be used with the output type.

**35 - No ATS Available**

This output type activates when no signalling paths are available for the Alarm Transmission System (ATS) and deactivates when one or more paths become available.

**36 - CIE Fault**

This output type activates when a fault occurs on the CIE and deactivates when the fault is cleared.

**37 - PSU Fuse Blown**

This output type activates when the Auxiliary input type 'PSU Monitor' detects a 12V failure and deactivates when the fault is reset.

**38 - PSU Battery Fit**

This output type activates when the Auxiliary input type 'PSU Monitor' detects a battery fault and deactivates when the fault is reset.

**39 - iD Loop Shorted**

This output type activates when the **24iXD** detects a short circuit on the iD loop and deactivates when the fault is reset

**40 - Radioplus Tamper**

This output type activates when the intelligent receiver detects a lid tamper.

**41 - GSM No Signal**

This output type activates when a GSM device loses the network signal.



## Output Group - Alarm

Select an output type from the following options:

### 00 - Alarm

This output type activates when a general alarm condition occurs, and deactivates when the alarm is cancelled.

### 01 - Guard Alarm

This output type activates when a zone programmed as 'Guard' causes an Intruder alarm and deactivates when the alarm is cancelled.

### 02 - Guard Access Alarm

This output type activates when a zone programmed as 'Guard Access' causes an Intruder alarm and deactivates when the alarm is cancelled.

### 03 - Entry Alarm

This output type activates when a zone programmed as 'Entry/Exit 1 or 2' causes an Intruder alarm and deactivates when the alarm is cancelled.

### 04 - Confirmed Alarm

If the system is already in alarm, this output type activates when a different zone (not on the entry route) is activated and deactivates at the end of the 'Confirmation' time, when a code is entered within the 'Abort' time or when the alarm is reset.

### 05 - 24Hr Audible

This output type activates when a zone programmed as '24Hr Audible' causes an Internal alarm or Intruder alarm and deactivates when the alarm is cancelled.

### 06 - Trouble

This output type activates when a zone programmed as 'Trouble' causes an alarm and deactivates when the alarm is cancelled.

### 07 - 24Hr Gas

This output type activates when a zone programmed as '24Hr Gas' causes a Silent alarm or Intruder alarm and deactivates when the alarm is cancelled.

### 08 - PA Alarm

This output type activates when any type of 'PA alarm' i.e. PA audible, PA silent or Duress causes a PA alarm and deactivates when the alarm is cancelled.

### 09 - PA Silent

This output type activates when a zone programmed as 'PA Silent' or a keypad PA (1 & 3) causes a silent PA alarm and deactivates when the alarm is cancelled.

### 10 - Duress

This output type activates when a User code with the 'Duress' attribute causes a silent PA alarm and deactivates when the alarm is cancelled..

### 11 - Fire Alarm

This output type activates when a zone programmed as 'Fire' or a keypad Fire (4 & 6) causes a Fire alarm and deactivates when the alarm is cancelled.

### 12 - Medical

This output type activates when a zone programmed as 'Medical' or a keypad Medical (7 & 9) causes a Medical alarm and deactivates when the alarm is cancelled.

### 13 - Auxiliary Alarm

This output type activates when a zone programmed as 'Auxiliary' causes a Silent alarm and deactivates when the alarm is cancelled.

### 14 - Tamper Alarm

This output type activates when a Tamper alarm is generated and deactivates when the alarm is cancelled.

### 15 - Alarm Abort

This output type activates when a User code is entered to cancel the alarm (within the 'Abort Delay' period and deactivates after 10 seconds.

### 16 - Ready

This output type activates when all zones are secure and deactivates when any zone is active.

### 17 - Entry Mode

This output type activates when the entry mode is started and deactivates when the entry mode finishes.

### 18 - 2<sup>nd</sup> Entry Mode

This output type activates when the 2<sup>nd</sup> entry timer starts and deactivates when the 2<sup>nd</sup> entry timer expires.

### 19 - Exit Mode

This output type activates when the exit mode is started and deactivates when the exit mode finishes.

### 20 - Entry/Exit Mode

This output type activates when the entry or exit mode is started and deactivates when the entry or exit mode finishes.

### 21 - Armed

This output type activates when the system is armed and deactivates when the system is disarmed.

### 22 - Full Armed

This output type activates when the system is fully armed and deactivates when the system is not fully armed.

### 23 - Part Armed

This output type activates when the system is part armed and deactivates when the system is not part armed.

### 24 - Force Arm

This output type activates when there is at least one zone with the 'Force Omit' attribute assigned to it, and deactivates when there are no zones with the 'Auto Omit' attribute assigned to it.

### 25 - Force Arming

This output type activates when the system has been forced to arm with zones active, and deactivates when the zone is reinstated.

### 26 - Arm Failed

This output type activates when the system fails to arm because a zone is in fault, and deactivates when the fault is reset.

**27 - Bell SAB**

This output type activates when an Alarm occurs and deactivates when the alarm is cancelled or the 'Bell Duration' timer expires.

**28 - Strobe**

This output type activates when an Alarm occurs and deactivates when the alarm is cancelled or the system is disarmed.

**29 - Detector Latch**

This output type activates for 5 seconds when the exit mode is started then reactivates when the system arms. The output type deactivates when an Intruder alarm occurs or the system is disarmed.

**30 - Detector Reset**

This output type is normally active and deactivates for 5 seconds when the exit mode is started.

**31 - Walk Test Active**

This output type activates when the 'Walk Test' procedure is started, and deactivates when the 'Walk Test' procedure is finished.

**32 - Zones Omitted**

This output type activates when a zone with the 'Omit' attribute, is omitted, and deactivates when the zone is reinstated.

**33 - 24Hr Zones Omit**

This output type activates when a zone programmed as '24Hr Audible' (with the 'Omit' attribute) is omitted by the user and deactivates when the zone is reinstated.

**34 - Reset Required**

This output type activates when the system requires a reset following an alarm and deactivates when the alarm is reset.

**35 - Door Strike**

This output type activates for the duration of the 'Door Strike' timer when a User code with the 'Door Strike' attribute is entered.

**36 - Chime Mimic**

This output type activates for 2 seconds when a zone with the 'Chime' attribute is activated.

**37 - Chime Enabled**

This output type activates when 'Chime' is enabled and deactivates when 'Chime' is disabled.

**38 - DK First Knock**

This output type activates when a zone with the 'Double Knock' attribute is activated for the first time and deactivates when the zone causes an alarm or the 'Double Knock Delay' timer expires.

**39 - On Test**

This output type activates when a zone with the 'Test' attribute is placed on test and deactivates when the 'Soak Test Time' expires.

**40 - Test Fail**

This output type activates when a zone with the 'Test' attribute activates and deactivates when an Engineer code is entered.

**41 - Internal Alarm**

This output type activates when an Internal alarm occurs and deactivates when the alarm is cancelled.

**42 - Time Arming**

This output type activates for 5 minutes prior to the system being armed using the 'Control Timers'.

**43 - Part Armed 1**

This output type activates when a Part Arm 1 is selected and deactivates when part arm 1 is not selected.

**44 - Part Armed 2**

This output type activates when a Part Arm 2 is selected and deactivates when part arm 2 is not selected.

**45 - Part Armed 3**

This output type activates when a Part Arm 3 is selected and deactivates when part arm 3 is not selected.

**46 - Zones Locked Out**

This output type activates when any zone is locked out following an Intruder Alarm activation and deactivates when all zones are clear and reinstated.

**47 - Armed/Alarm**

This output type activates when the system is armed and deactivates when the system is disarmed.

This output type also pulses when an Intruder alarm occurs, and deactivates when the system is disarmed.

**48 - Full Arm Entry**

This output type activates when the entry mode is started and deactivates when the entry mode finishes whenever the system in Full Armed.

**49 - Intruder Alarm**

This output type activates when an Intruder alarm occurs, and deactivates when the Intruder alarm is cancelled.

Tamper alarms will not activate this output

**50 - Speaker Mimic**

This output type activates whenever the internal speaker output is on, and deactivates when the speaker output is off.

**51 - Detector Fault**

This output type activates when a detector fault occurs and deactivates when the fault is reset.

**52 - Detector Masked**

This output type activates when a detector mask occurs and deactivates when the mask is reset.

**53 - Fault Present**

This output type activates when a general fault occurs i.e. Line Fault, AC Mains Fail, Detector Fault etc. and deactivates when the fault is cleared.

**54 - LED Control**

This output type is always activate and deactivates when a User or Engineers code is entered to gain access to a menu. The output activates again 30 seconds after the user/engineer exits the menu. This output type is for use with detectors that require 0V applied to disable their LED's.

## Output Group - Zone

Any zone can be assigned to each output type. Select a zone number from 1 to 48 (*Premier 48*), 1 to 88 (*Premier 88*) or 1 to 168 (*Premier 168*) then select an output type from the following options:

### Mimic

This output type activates when the selected zone is activated and deactivates when the zone is secure. This output will work if the zone is armed or disarmed.

### Alarm

This output type activates when the selected zone causes an alarm and deactivates when the alarm is reset. This output will only work if the zone is armed.

## Output Attributes

Assigning an attribute to an output will alter how the output works. The following attributes can be assigned to any of the various types listed.



**NOTE** Select attributes by pressing keys 1 to 4 (a letter on the display means the attribute is selected, a star on the display means the attribute is not selected).

### U - User Test

The output will activate when a user performs a User test (see page 79 for details).

### I - Inverted

The output is inverted (an output that applies 0V when active will become an output that applies 12V when active).

### L - Latching


When activated, the output will remain on until a valid User code is entered.

### 1 - Pulsed

When activated, the output will remain on for the duration of the 'Pulse Period 1' timer (see page 43 for details).

## Custom Output (PGM5-8)

Custom outputs are NOT physical outputs they are 'Software outputs that can be configured to operate under certain conditions. Once configured these outputs can then be assigned to a physical output (see system output 21, page 56 for details).



### Example

PGM5 is programmed as: **Zone 1 Mimic**

PGM6 is programmed as: **Zone 2 Mimic**

PGM7 is programmed as: **Armed**

PGM8 is programmed as: **Never Active (and inverted)**




**NOTE** The Custom Output will only activate when switches 1 OR 2 AND 3 AND 4 are closed.

i.e. if ZONE 1 or ZONE 2 ACTIVATES whilst the system is ARMED (switch 4 is always closed).


## 5.7 UDL/Digi Options

### Reset Digi




This option should be used whenever a *Premier* plug-on communicator is plugged on or removed from the control panel.



### Start Test Call



When a *Premier* plug-on communicator has been fitted to the control panel. This option can be used to send a test call to the Alarm Receiving Centre or to initiate a remote Upload/Download call to one of the programmed callback numbers.

## Program Digi





The plug-on digimodem can be programmed with up to 2 sets of Alarm Receiving Centre (ARC) information. Each 'Set' consists of the following options:


### **Protocol**

This is the reporting protocol that is used to communicate with the Alarm Receiving Centre. The following 4 protocols are supported:

- **Fast Format:** The panel will report using Fast Format. If this option is selected the 'Reporting Channels' must be programmed (see below)
- **Contact ID:** The panel will report using Contact ID.
- **SIA Level II:** The panel will report using SIA Level II
- **SMS Messaging:** The panel will send Short Message Service (SMS) text messages to a mobile phone

### **Primary Telephone Number**

This is the first telephone number that the digimodem will dial for the Alarm Receiving Centre or the first mobile telephone number to send SMS to. This telephone number can be up to 24 digits.

When entering telephone numbers, pressing  repeatedly will allow the following characters to be selected:

\*#, (3 second pause) W (10 second pause) + R (recall signal).

### **Secondary Telephone Number**

This is the second telephone number that the digimodem will dial for the Alarm Receiving Centre or the second mobile telephone number to send SMS to. This telephone number can be up to 24 digits.

### **Account Number**

This is the account number that will be reported to the Alarm Receiving Centre. Each account number can be up to 6 digits.

### **Dialling Attempts**

This is the number of times the digimodem will try to dial the Alarm Receiving Centre or Pager telephone number.



**NOTE** The number of dialling attempts is limited to 9. If this value is set to 0, the digimodem will never dial out.

### **The following option is only displayed if the Fast Format protocol is selected**

#### **Reporting on**

This option defines which channels report to the selected Alarm Receiving Centre.

#### **Restoring on**

This option defines which channels report a restore to the selected Alarm Receiving Centre.

#### **Open/Close on**

This option defines which channels report Open/Close to the selected Alarm Receiving Centre.

### **The following option is only displayed if Contact ID, SIA Level II or EasyCom Pager protocols are selected**

#### **Reports**

This option defines which events report to the Alarm Receiving Centre when using Contact ID or SIA Level II. The following options are available:

#### **P - Priority Alarm and Cancel Events**

The system will report Priority alarm and cancel events to the selected Alarm Receiving Centre.

#### **A - Normal Alarm and Cancel Events**

The system will report alarm and cancel events to the selected Alarm Receiving Centre.

#### **O - Open and Close Events**

The system will report open and close events to the selected Alarm Receiving Centre.

#### **O - Omit and Reinstate Events**

The system will report omit and reinstate events to the selected Alarm Receiving Centre.

#### **M - Maintenance Alarm Events**

The system will report maintenance alarm events to the selected Alarm Receiving Centre.

#### **T - Tamper Alarm Events**

The system will report tamper alarm events to the selected Alarm Receiving Centre.

#### **C - Test Call Events**

The system will report test call events to the selected Alarm Receiving Centre.

#### **R - Restore Events**

The system will report restore events to the selected Alarm Receiving Centre.

### **The following option is only displayed if Fast Format Contact ID or SIA Level II protocols are selected**

#### **Config.**

This option defines which secondary options are enabled. The following options are available:

#### **D - Disable Zone Res**

The system will NOT report zone restore events to the selected Alarm Receiving Centre.

#### **S - SIA Level I**

The system will report events to the selected Alarm Receiving Centre using SIA Level I.

#### **R - Enable Radio-Pad**

The system will use the Paknet radio-pad to report events to the selected Alarm Receiving Centre.


#### **G - Enable ComGSM**

The system will use the **ComGSM** to report events to the selected Alarm Receiving Centre (see page 6 for details).

#### **F - Use GSM First**

The **ComGSM** is the primary path when it is enabled

## Digi Options



There are 5 options that control how the plug-on Digimodem works.

Select options by pressing keys 1 to 8 (a letter on the display means the option is selected, a star on the display means the option is not selected).

### **E – Digi is Enabled (Default = OFF)**

The plug-on Digimodem will report all system events to the Alarm Receiving Centre.

### **P – Pulse Dialling (Default = OFF)**

The plug-on Digimodem will always dial telephone numbers using pulse dialling.

### **3 – Pulse After 3 (Default = OFF)**

The plug-on Digimodem will always dial telephone numbers using tone dialling. However, if the Digimodem fails to dial the number three times in a row, it will revert to pulse dialling for the remaining attempts.

### **B – Blind Dialling (Default = OFF)**

The plug-on Digimodem will not look for a dial tone before dialling a telephone number.

### **R – Reserved (Default = OFF)**


This option is not used.

### **A – Dial All Numbers (Default = OFF)**

The Digimodem will not shut down until an acknowledgement has been received from all programmed telephone numbers.




## UDL Options



The system has the following download options:

### **PC No. 1**

This is the telephone number that is dialled by the modem when 'Call-back Number 1' is requested by the remote UDL computer.

When entering telephone numbers, pressing  repeatedly will allow the following characters to be selected:

\*#, (3 second pause) W (10 second pause) + R (recall signal).

### **PC No. 2**

This is the telephone number that is dialled by the modem when 'Call-back Number 2' is requested by the remote UDL computer.

### **UDL ID:**

When the remote downloading computer dials into the system, the control panel compares the UDL password sent by the computer with UDL password stored in the control panel. If the passwords match, access to the control panel is granted, if they don't match, access is denied.



If more than three attempts at reporting are made with a wrong password, the modem will lock out for 4 hours or until a User code is entered.

The UDL password programmed in this option must also be programmed in the customer account on the remote downloading computer. This password can be up to 16 characters (numbers and letters).

If no UDL Password has been programmed, access to the control panel can be gained by using the engineers code as the UDL Password.

### **UDL Options**

There are 6 UDL options that affect how and when access to the control panel via the *Wintex UDL* software is allowed.

Select options by pressing keys 1 to 6 (a letter on the display means the option is selected, a star on the display means the option is not selected).

The following UDL options are available:

### **A - DL Attended (Default = OFF)**

The system will not allow the remote downloading computer access without for user authorisation first.

### **M - Man Call-Back (Default = ON)**

The system will not use the automatic call back feature. The user must instruct the panel to call back the remote downloading computer.

The Auto Call-Back feature operates as follows:

- The remote downloading computer calls the control panel and establishes a connection
- The UDL password is verified and the remote downloading computer instructs the panel to call it back using one of the 3 call back numbers
- The panel hangs up and dials the requested number and re-establishes the connection with the remote downloading computer

### **D - Call Defeat (Default = ON)**

The modem will answer incoming calls as follows:

- The modem must detect one or more rings and the number of rings must NOT exceed the value set up in 'Rings Required'
- When the ringing stops, the panel will start a 30 second delay timer
- If the modem detects ringing before the timer expires it will answer the call immediately

### **L - Armed DL Limited (Default = OFF)**

The panel will not allow download access when the system is armed (also see below).

### **A - Only Full Armed (Default = OFF)**

The panel will not allow download access when the system is fully armed.

### **K - Online RKP=Off (Default = OFF)**

The control panel cannot be accessed using the 'On-line' keypad feature of the *Wintex UDL* software.

### **Rings Required**

This counter controls the number of rings the modem needs to see before it will answer the call (Default = 005).

### **UDL Dial Attempt**


If a 'Call-Back' is started, this option controls how many times the modem will try to call the remote downloading computer before giving up (Default = 003).



Enter the number of dialling attempts. This number is limited to 9. If this value is set to 0, the Digimodem will never dial out.

This only affects the modem for download access and does not affect the operation of the Digimodem in any way.

## Radio/SMS Options



### Pad ARC 1 Pri No

This is the first number that is used by the Radio-Pad for reporting events to ARC set 1.

### Pad ARC 1 Sec No

This is the second number that is used by the Radio-Pad for reporting events to ARC set 1.

### Pad ARC 1 Prefix

This number will prefix the account number for ARC 1.

### Pad ARC 2 Pri No

This is the first number that is used by the Radio-Pad for reporting events to ARC set 2.

### Pad ARC 2 Sec No

This is the second number that is used by the Radio-Pad for reporting events to ARC set 2.

### Pad ARC 2 Prefix

This number will prefix the account number for ARC 2.


### SMS Centre Pri.

This is the first SMS centre telephone number that is used by for sending SMS to mobile phones. (Default = 07860 980480).

### SMS Centre Sec.

This is the second SMS centre telephone number that is used by for sending SMS to mobile phones.

## Com Port Setup



The control panel must be programmed with the type of device that is connected to each of its com ports.

### Onboard Digicom

This option determines what type of device is connected to the plug-on digimodem connector (Default = Com300).

### Com1

This option determines what type of device is connected to the Com1 connector (Default = No Module Fitted).

### Com2

This option determines what type of device is connected to the Com2 connector (Default = No Module Fitted).

### Available Device Types

No Module Fitted  
Com300  
Com2400  
ComISDN  
Paknet Radio-Pad  
GSM Module

## Zone Alarm Reporting Codes

The Reporting codes for Contact ID and SIA are fully configurable, however these codes can only be changed using *Wintex* downloading software.

The following tables show the default codes for each event on the system:

### Default Zone Event Codes

No	Zone Type	Event	Reporting Group	Contact ID	SIA
00	Entry/Exit 1	Alarm	Alarm	134	BA
		Alarm Restore	Restore	134	BH
		Omit	Omit/Reinstate	573	BB
		Reinstate	Omit/Reinstate	573	BU
01	Entry/Exit 2	Alarm	Alarm	134	BA
		Alarm Restore	Restore	134	BH
		Omit	Omit/Reinstate	573	BB
		Reinstate	Omit/Reinstate	573	BU
02	Guard	Alarm	Alarm	132	BA
		Alarm Restore	Restore	132	BH
		Omit	Omit/Reinstate	573	BB
		Reinstate	Omit/Reinstate	573	BU
03	Guard Access	Alarm	Alarm	132	BA
		Alarm Restore	Restore	132	BH
		Omit	Omit/Reinstate	573	BB
		Reinstate	Omit/Reinstate	573	BU
04	24Hr Audible	Alarm	Tamper	133	BA
		Alarm Restore	Restore	133	BH
		Omit	Omit/Reinstate	572	BB
		Reinstate	Omit/Reinstate	572	BU
05	Forced Entry	Alarm	Tamper	133	BA
		Alarm Restore	Restore	133	BH
		Omit	Omit/Reinstate	572	BB
		Reinstate	Omit/Reinstate	572	BU
06	Audible PA	Alarm	Priority Alarm	123	PA
		Alarm Restore	Restore	123	PH
		Omit	Omit/Reinstate	573	PB
		Reinstate	Omit/Reinstate	573	PU
07	Silent PA	Alarm	Priority Alarm	122	HA
		Alarm Restore	Restore	122	HH
		Omit	Omit/Reinstate	573	HB
		Reinstate	Omit/Reinstate	573	HU
08	Fire Alarm	Alarm	Priority Alarm	110	FA
		Alarm Restore	Restore	110	FH
		Omit	Omit/Reinstate	571	FB
		Reinstate	Omit/Reinstate	571	FU
09	24Hr Gas Alarm	Alarm	Tamper	151	GA
		Alarm Restore	Restore	151	GH
		Omit	Omit/Reinstate	572	GB
		Reinstate	Omit/Reinstate	572	GU

No	Zone Type	Event	Reporting Group	Contact ID	SIA
10	Auxiliary Alarm	Alarm	Tamper	150	UA
		Alarm Restore	Restore	150	UH
		Omit	Omit/Reinstate	572	UB
		Reinstate	Omit/Reinstate	572	UU
11	24Hr Tamper Alarm	Alarm	Tamper	137	TA
		Alarm Restore	Restore	137	TR
		Omit	Omit/Reinstate	572	TB
		Reinstate	Omit/Reinstate	572	TU
12	Exit Terminator	Alarm	Open/Close	---	--
		Alarm Restore	Open/Close	---	--
		Omit	Omit/Reinstate	570	UB
		Reinstate	Omit/Reinstate	570	UU
13	Keyswitch	Alarm	Open/Close	409	OP
		Alarm Restore	Open/Close	409	CL
		Omit	Omit/Reinstate	570	UB
		Reinstate	Omit/Reinstate	570	UU

### Non-Zone Event Types

The default Non-Zone Event codes are as follows:

No	Type	Event	Reporting Group	Contact ID	SIA	ID
20	Keypad Medical	Alarm	Priority Alarm	100	MA	Keypad No *
		Restore	Restore	100	MH	Keypad No *
21	Keypad Fire	Alarm	Priority Alarm	115	FA	Keypad No *
		Restore	Restore	115	FH	Keypad No *
22	Keypad Audible PA	Alarm	Priority Alarm	120	PA	Keypad No *
		Restore	Restore	120	PH	Keypad No *
23	Duress Code Alarm	Alarm	Priority Alarm	122	HA	User No
		Restore	Restore	122	HH	User No
24	Keypad Silent PA	Alarm	Priority Alarm	121	PA	Keypad No *
		Restore	Restore	121	PH	Keypad No *
25	Alarm Active	Alarm	-	-	-	-
		Restore	-	-	-	-
26	Bell Active	Alarm	-	-	-	-
		Restore	-	-	-	-
27	Re-arm	Alarm	Alarm	-	-	Zone No
		Restore	-	-	-	-
28	Verified Cross Zone Alarm	Alarm	Alarm	130	BV	00
		Restore	-	-	-	-
29	User Code	Alarm	-	-	-	User No
		Restore	-	-	-	-
30	Exit Started	Alarm	-	-	-	Keypad No
		Restore	-	-	-	-
31	Exit Error (Arming Failed)	Alarm	Open/Close	457	EE	00
		Restore	-	-	-	-
32	Entry Started	Alarm	-	-	-	-
		Restore	-	-	-	-
33	Area Arm Suite	Alarm	Open/Close	-	-	Suite No 1 – 8
		Restore	Open/Close	-	-	-

No	Type	Event	Reporting Group	Contact ID	SIA	ID
34	Armed with Line Fault	Alarm	-	-	-	User No
		Restore	-	-	-	-
35	Open/Close (Full Arm)	Alarm	Open/Close	401	OP	User No
		Restore	Open/Close	401	CL	User No
36	Open/Close (Part Arm)	Alarm	Open/Close	401	OP	User No
		Restore	Open/Close	401	CL	User No
37	Auto Open/Close	Alarm	Open/Close	403	OA	00
		Restore	Open/Close	403	CA	00
38	Auto Arm Deferred	Alarm	Open/Close	405	CE	User No
		Restore	Open/Close	-	-	-
39	Open After Alarm (Alarm Abort)	Alarm	Open/Close	406	OR	00
		Restore	-	-	-	-
40	Remote Open/Close	Alarm	Open/Close	407	OP	00
		Restore	Open/Close	407	CL	00
41	Quick Arm	Alarm	-	-	-	-
		Restore	Open/Close	408	CL	Keypad No *
42	Recent Closing	Alarm	Open/Close	459	CR	00
		Restore	-	-	-	-
43	Reset After Alarm	Alarm	Restore	-	-	Reset ID ****
		Restore	-	-	-	-
44	Auxiliary 12V Fuse Fail	Alarm	Maintenance	300	YP	Device ID **
		Restore	Restore	300	YQ	Device ID **
45	AC Fail	Alarm	Maintenance	301	AT	00
		Restore	Restore	301	AR	00
46	Low Battery	Alarm	Maintenance	302	YT	00
		Restore	Restore	302	YR	00
47	System Power Up	Alarm	Maintenance	305	RR	00
		Restore	-	-	-	-
48	Bell Fuse Failure	Alarm	Maintenance	321	YA	00
		Restore	Restore	321	YH	00
49	Telephone Line Fault	Alarm	Maintenance	351	LT	Line Fault ID ***
		Restore	Restore	351	LR	Line Fault ID ***
50	Fail to Communicate	Alarm	Maintenance	354	YC	00
		Restore	-	-	-	-
51	Reporting Successful	Alarm	-	-	-	-
		Restore	-	-	-	-
52	Communicator Active	Alarm	-	-	-	-
		Restore	-	-	-	-
53	Download Start	Alarm	Maintenance	411	RB	00
		Restore	-	-	-	-
54	Download End	Alarm	Maintenance	412	RS	-
		Restore	-	-	-	-
55	Log Capacity Alert (80%)	Alarm	Maintenance	623	JL	00
		Restore	-	-	-	-
56	Date Changed	Alarm	Maintenance	625	JD	User No
		Restore	-	-	-	-

No	Type	Event	Reporting Group	Contact ID	SIA	ID
57	Time Changed	Alarm	Maintenance	625	JT	User No
		Restore	-	-	-	-
58	Installer Programming Start	Alarm	Maintenance	627	LB	User No
		Restore	-	-	-	-
59	Installer Programming End	Alarm	Maintenance	628	LS	User No
		Restore	-	-	-	-
60	Panel Box Tamper	Alarm	Tamper	145	TA	00
		Restore	Restore	145	TR	00
61	Bell Tamper	Alarm	Tamper	145	TA	Device ID **
		Restore	Restore	145	TR	Device ID **
62	Auxiliary Tamper	Alarm	Tamper	145	TA	Device ID **
		Restore	Restore	145	TR	Device ID **
63	Expander Tamper	Alarm	Tamper	145	TA	Device ID **
		Restore	Restore	145	TR	Device ID **
64	Keypad Tamper	Alarm	Tamper	145	TA	Keypad No *
		Restore	Restore	145	TR	Keypad No *
65	Expander Trouble (Network Error)	Alarm	Tamper	333	ET	Device ID **
		Restore	Restore	333	ER	Device ID **
66	Keypad Trouble (Network Error)	Alarm	Tamper	333	ET	Keypad No *
		Restore	Restore	333	ER	Keypad No *
67	Fire Zone Tamper	Alarm	Tamper	373	FT	Zone No
		Restore	Restore	373	FJ	Zone No
68	Zone Tamper	Alarm	Tamper	383	TA	Zone No
		Restore	Restore	383	TR	Zone No
69	Keypad Lockout	Alarm	Tamper	421	JA	Keypad No *
		Restore	-	-	-	-
70	Code Tamper Alarm	Alarm	Tamper	421	JA	Keypad No *
		Restore	-	-	-	-
71	Soak Test Alarm	Alarm	Test	-	-	Zone No
		Restore	Restore	-	-	Zone No
72	Manual Test Call	Alarm	Test	601	RX	00
		Restore	-	-	-	-
73	Automatic Test Call	Alarm	Test	602	RP	00
		Restore	-	-	-	-
74	User Walk Test Start/End	Alarm	Test	607	TS	User No
		Restore	Restore	607	TE	User No

**Keypad No \***

Keypad ID is transmitted as follows:

Remote Keypad	Network 1
1	101
2	102
3	103
4	104

**Device ID \*\***

Device ID is transmitted as follows:

Device	ID
Panel	000
	<b>Net 1</b>
Expander 1	101
Expander 2	102

**Line Fault ID \*\*\***

Line Fault ID is transmitted as follows:

Device	ID
Panel	000
Com300	003
Expander 1	001
Expander 2	002


**Reset ID \*\*\*\***

Reset ID is transmitted as follows:

Device	ID
Engineer/User	000
Panel (RR)	001
RedCARE	002
Expander 1	001
Expander 2	002



## 5.8 Setup Users



## Adding New Users to the System

This section covers the alteration of existing users and the addition of new users to the system. The *Premier 24* can be assigned up to 15 users (plus Engineer).

### Default User Codes

When the control panel is first powered up and the factory default settings are loaded (see page 28 for details), only the Engineer code and the Master User code exist.

The default Engineer user code is **1** **2** **3** **4**.



NOTE The Engineer is always User 00.

If the Engineer code has been lost or forgotten, it can normally be reset back to 1234 without having to default the entire system (see page 33 for details).

Resetting the Engineer code is only possible if the NVM has not been locked (see page 44 for details).

The default Master user code is **5** **6** **7** **8**.



NOTE The Master User is always User 01.

If the Master User code has been lost or forgotten, it can be reprogrammed by the Engineer in this menu.

## Programming New Users

Each User code on the system is made up of the following elements **1**, **2** or **6**, **3** and **4**, these are essential for the code/TAG to function correctly, item **5** is optional.

### 1. User Number

When users are assigned to the system, they need to be identified by the control panel. Each user is identified as Users 01, 02, 03 etc. User 01 is always the Master User.

### 2. User Code

This is a unique 4, 5 or 6 digit code number that is assigned to a user. The system will allow a mixture of different length User codes. The User code must be entered at a keypad to operate the alarm system.

### 3. User Types

The User type determines which options the user can access i.e. Setup Users, System Tests etc.

### 4. User Options

The User Options determines which functions are available to the user i.e. arming, disarming, omitting etc.

### 5. User Name Text

Each user can be assigned up to 8 characters of name text. The name text is displayed whenever a code is entered and also when reading the log, making identification of people using the alarm easier.

### 6. Proximity TAG

As well as or instead of operating the alarm system with a code number, it is also possible to operate it by presenting a Proximity TAG to the keypad (this requires a Proximity keypad).

## User Types

The User type determines which functions are available to the user i.e. arming, disarming etc. In addition, the User type also determines which options the user can access i.e. Setup Users etc. The following User types are available:

### 0: Engineer

Engineers can arm, disarm, omit zones, silence alarms and reset alarms. In addition, Engineers can access the Programming Menu and all User menu options. Engineers can also change their own User codes and assign new users to the system.



NOTE The default Engineer User type (User 00) can assign any User types to the system.

Engineers can only disarm the system if it was armed using an Engineer code. They cannot disarm the system if it was armed with a User code.

### 1: Master

Master users can arm, disarm, omit zones, silence alarms and reset alarms. In addition, Master users can access all User menu options. Master users can also change their own User codes and assign new users to the system. The Master user will also activate any output programmed as 'Door Strike'.

### 2: Manager

Manager users can arm, disarm, omit zones, silence alarms and reset alarms. In addition, Manager users can access all User menu options except Setup Users. Manager users can also change their own User codes.

### 3: Standard

Standard users can arm, disarm, omit zones, silence alarms and reset alarms. In addition, Standard users can access all User menu options except for Setup Users, System Tests, and Change Timers. Standard users can also change their own User codes.

### 4: Shunt

Shunt users are able to omit and reinstate any zone that has been programmed as 'Shunable'.

### 5: Duress

Duress users behave the same way as Standard users. However, Duress users will activate any outputs programmed as 'Panic Alarm' or 'Duress' whenever their code is entered.

### 6: Reset Only

Reset Only users can only disarm following an alarm and then reset and rearm the alarm again.

### 7: Door Strike





Door Strike users have no access to User functions or Menu options. However, Door Strike users will activate any outputs programmed as 'Door Strike' whenever their code is entered (see page 58 for details).

## User Options

This menu is only displayed if the Custom User type is selected (see page 75 for details).

This menu defines which options are available to the user when their code is entered.

Some of the following options may not always be selectable or de-selectable.

Press  to scroll through the options and press  to select them or use keys  -  ('Letter' = option **IS** selected, 'Star' = option is **NOT** selected).

The following options are available:

### A – Arming

The selected user can be armed.

### D – Disarming

The selected user can be disarmed.

### O – Omitting

The selected user can omit zones providing that they have the 'omit' attribute assigned to them (see page 36 for details).

### T – Lock TAG = PGM2

The Users TAG is disabled whenever PGM2 is active.


### C – Lock Code = PGM3

The Users code is disabled whenever PGM3 is active (default = during the Full Arm Entry mode).

### U – Lock User = PGM4

The Users TAG and Code is disabled whenever PGM4 is active (default = Control Timer 4).

### Y – Auto 'YES'


After a User code has been entered, pressing the  key to confirm the next action is not required.

### O – Open/Close

The selected user will report open (disarm) and close (arm) events to an Alarm Receiving Centre every time they arm or disarm.

## User Name Text

Each user can be assigned up to 8 characters of name text. This can be beneficial when reading the log, as identification of people is made easier.




Text is programmed in a similar way to mobile phones. Select characters by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the  key to move the cursor along).

## Programming Proximity TAGS

To program TAGS proceed as follows:

Ensure that Setup Users is selected, the display should look like this:

```
Setup Users
Enter User --
```

Select a user   then press 

```
Do you want to
Add TAG to User?
```

Press 

```
Present TAG NOW !
```

Present the TAG to the 'Prox' symbol on the keypad

(A confirmation tone will be heard)

Press  when finished

Press  to exit the menu




The display will return to normal.

## Deleting User Codes

To delete User codes proceed as follows:

Ensure that Setup Users is selected, the display should look like this:

```
Setup Users
Enter User --
```

Select a user   then press 

```
Enter User Code>
-----
```

Press 

```
Do you want to
DELETE User 15
```

Press  to confirm deletion of the selected User code

Press  when finished

Press  to exit the menu

The display will return to normal.

## Available Options

The table below shows the options that are available to each user.

User Options								
	Code Type							
Options	Engineer	Master	Manager	Standard	Shunt	Duress	Reset Only	Door Strike
Arming	✓	✓	✓	✓		✓		
Disarming	✓	✓	✓	✓		✓		
Omitting	✓	✓	✓	✓				
Lock by PGM2								
Lock by PGM3								
Lock by PGM4								
Auto YES								
Open/Close	✓	✓	✓	✓	✓	✓	✓	


Arming Menu								
	Code Type							
Options	Engineer	Master	Manager	Standard	Shunt	Duress	Reset Only	Door Strike
Enable Chime	✓	✓	✓	✓		✓		
View Zones	✓	✓	✓	✓		✓		
Door Strike								✓

User Menu								
	Code Type							
Options	Engineer	Master	Manager	Standard	Shunt	Duress	Reset Only	Door Strike
View Event Log	✓	✓	✓	✓			✓	
Change Code	✓	✓	✓	✓				
Chime Zones	✓	✓	✓					
Bell Test	✓	✓	✓					
Walk Test	✓	✓	✓					
Enable Engineer	✓	✓	✓	✓				
Program Time	✓	✓						
Program Date	✓	✓						
Setup Users	✓	✓						
Alter Part Arms	✓	✓						
Call Rem. PC	✓	✓	✓	✓				
Edit Phone No's	✓	✓						

Engineer Menu								
	Code Type							
Options	Engineer	Master	Manager	Standard	Shunt	Duress	Reset Only	Door Strike
Engineer Program	✓							

## 5.9 Engineer Utilities

### View Event Log



The control panel has two Event Logs, which are time and date stamped. The first log is a 500 event system log which records all events that occur on the system, i.e. Users entering their codes to arm or disarm, alarm events, failures to arm etc.

The second log is a 500 event Mandatory log which records only events defined as 'mandatory' by **EN50131**.

### Event Log Hotkeys

When viewing the system log there are 10 hotkeys available. These hotkeys allow certain events to be found easier without the need for searching.

The following hotkeys are available:


- ① = Priority Alarms (PA, Fire etc.)
- ②<sub>abc</sub> = Normal Alarms (Guard, 24hr, Entry/Exit etc.)
- ③<sub>def</sub> = Opens and Closings (Arm, Disarm etc.)
- ④<sub>ghi</sub> = Omits and Reinstates (Zone Omits etc.)
- ⑤<sub>jkl</sub> = Maintenance (System Tests, Engineer Program etc.)
- ⑥<sub>mno</sub> = Tamperers (Zone, Bell, Aux etc.)
- ⑦<sub>pqrs</sub> = Test Calls (Communicator Active, successful etc.)
- ⑧<sub>tuv</sub> = Entry/Exit (Entry and Exit Procedures)
- ⑨<sub>wxyz</sub> = User Codes (User codes being used)
- Area = Switch between Event Log & Mandatory Log

### Event Log Descriptions

Log Event	Description
KSW ## Active	A Keyswitch zone type has been activated (zone number ##)
RKP # MEDICAL	A Medical alarm (7 & 9) has occurred from keypad number #
RKP #.# FIRE	A Fire alarm (4 & 6) has occurred from keypad number #
RKP AUD PA #	An Audible PA alarm (1 & 3) has occurred from keypad number #
RKP SIL PA #	A Silent PA alarm (1 & 3) has occurred from keypad number #
DURESS	User ## has entered a Duress Code at a keypad
ALARM Active	An Intruder alarm signal has been activated
BELL Active	The Bell output has been activated
REARM LOCK ##	Zone ## has locked out after reaching its re-arm limit (after causing an alarm)
USER ##	User ## has entered their code
EXIT	The Exit mode has been started
ARMING FAILED	A Exit Error-Arm Fail has occurred
ENTRY	The Entry mode has been started
ARMED WITH L/F	The system has been armed with a Line Fault condition present
Armed	The system has been armed
Disarmed	The system has been disarmed
PART Armed	The system has been Part Armed
TIME Armed	The system was armed automatically using one of the control timers
TIME Disarmed	The system was disarmed automatically using one of the control timers
DEFERRED	The automatic arming mode was deferred
ALARM ABORT	An Open After Alarm-Abort has occurred
REMOTE Armed	The system was armed using the <i>Wintex UDL</i> software
REMOTE Disarmed	The system was disarmed using the <i>Wintex UDL</i> software
QUICK Armed	Quick Arm from keypad #
RECENT Armed	The system has been armed recently

Log Event	Description
# RESET -	The system has been reset using keypad # following an Intruder alarm
Engineer Reset	A reset has been performed using an Engineers code
Anti-Code Reset	A reset has been performed using the Anti-code reset procedure
Remote Reset	A reset has been performed using the 'Remote Reset' input
Key switch Reset	A reset has been performed using a key switch
User Reset	A reset has been performed using a User code
EXP # Reset	A reset has been performed using the input on expander # (programmed as reset)
Remote PC Reset	A reset has been performed by the remote download PC
FUSE # FAIL	The Auxiliary 12V Fuse/PTC in device # has failed
AC POWER	The control panel has registered a AC Mains failure
LOW BAT	The control panel has registered a low battery condition
POWERED UP	System Power Up (without doing a factory restart)
BELL FUSE	The control panel Bell Fuse has failed
LINE FLT	There is a problem with the telephone line
Panel Line Fault	The control panel line fault input has been activated
Com??? Line Fault	The Com300, 2400 or ISDN has detected a line fault
COMS FAILED	The Com300 or Com2400 has failed to report to the Alarm Receiving Centre
DOWNLOAD START	An Upload/Download has been initiated
DOWNLOAD END	The Upload/Download has finished
LOG ALERT	80% of the Event Log has filled (since the last Upload/Download)
DATE CHANGED	The control panel Time has been changed
TIME CHANGED	The control panel Date has been changed
PROG. START	An Engineer code has been entered
PROG. END	The Engineer has logged out of the Programming menu
BOX LID	The control panel lid has been removed causing a Tamper alarm
BELL # Tamper	A Bell Tamper input from device # has been activated
AUX # Tamper	An Auxiliary Tamper input from device # has been activated
EXP # Tamper	The cover of expander # has been removed
RKP # Tamper	The cover of keypad # has been removed
RKP # LOST	Keypad ## has been lost from the network
EXP # LOST	Expander ## has been lost from the network
FIRE ## Active	Zone ## (programmed as Fire Alarm) has caused an alarm
Zone ## Tamper	Zone ## has caused a Tamper alarm
Zone ## Active	Zone ## has been activated
Zone ## Restore	Zone ## has restored to its normal condition
Zone ## Omitted	Zone ## has been omitted
Zone ## Un-Omit	Zone ## has been reinstated
Zone ## Test Start	Zone ## has been put on test
Zone ## Test End	Zone ## has been removed from test
RKP LOCKED #	Keypad # has been locked out from too many invalid key presses
CODE # Tamper	Too many invalid key presses have caused a tamper alarm from keypad #
TEST FAIL ##)	Zone ## has failed its Soak test
MANUAL TEST CALL	A Manual test call has been initiated
AUTO TEST CALL	An Automatic test call has been initiated
WALK	The Walk Test mode has been initiated
TESTED ##	Zone ## has been tested
DEFAULTS LOADED	The factory default values have been loaded into memory
FIRST KNOCK ##	Zone ## (which is programmed as double knock) has activated for the first time
CURRUPT EVENT	No event has been stored in memory

## Do Bell Test




This option allows the Bell, Speaker and various control panel outputs to be tested.

The following outputs can be individually tested:

<b>Test Bell</b>	The Bell output
<b>Test Strobe</b>	The Strobe output
<b>Test Speaker</b>	The Speaker output
<b>LCD Display</b>	The LCD keypad display
<b>User Outputs</b>	Any outputs that have the 'User Test' attribute (see page 59 for details).
<b>Test Panel</b>	The 6 panel outputs
<b>Test Comm</b>	The 8 plug on digi outputs

## Do Walk Test




Any of the zones on the system can be walk tested to ensure that they operate correctly. A walk test can only be performed when the system is disarmed.



Once a zone has been activated it will not generate a chime tone again. If however the **Chime** key is pressed, a zone will chime every time it is activated.

Pressing the **Area** key will display the zone text associated with the zones.

## View Zone Status




This option can be used to view the status of any zone on the system to see whether it is 'Active', 'Secure', 'Tampered' or 'Shorted'. The selected zone can also be temporarily disabled (zone and tamper) to allow the zone to be worked on or made to chime every time it is activated.




**NOTE** When leaving the View Zone Status menu, all zones will be automatically reinstated and cleared of Chime.

## View System Status



This option allows the control panel software version and some system parameters to be viewed.

## Confirm Devices




This option allows the networks to be viewed to see what devices are connected and whether there are any problems. Whenever new devices are added to the system, the networks must be checked and confirmed.



**NOTE** If any devices are removed from the system, the networks must be rechecked and reconfirmed.




## View RKP Status




This option allows the status of the keypad, the zones and the output to be viewed.

## Check Exp. Status




This option allows the status of the expander, the zones, voltage/inputs and outputs to be viewed.

## Set System Time




The control panel has a real time clock that is used to date and time stamp events that are recorded within the system log. The option allows you to set the control panel time.

## Set System Date




The control panel has a real time clock that is used to date and time stamp events that are recorded within the system log. The option allows you to set the control panel date.

## Change Eng. Code




This option allows the Engineer code (User 00) to be changed. This code can be 4, 5 or 6 digits in length. The system will allow a mixture of different length User codes.

## Print Log




This option allows up to 250 events to be printed to a serial printer connected to com port 1.

## View iD Status



This option allows the current status of all iD devices to be viewed on a single screen.

## Configure Radio



The **Intelligent Radio Receiver** or **Network Receiver** provide the facility to use wireless detection devices and Fobs. Up to 32 wireless devices can be connected, including upto 24 detection devices and up to 16 fobs (combined total cannot exceed 32 devices).

Wireless devices can then be mapped on to the system along with conventional detectors.

The top line on the display shows the serial number of the device and also the status i.e. Active, Tamper etc.

The bottom line of the display shows the signal strength and also which zone/user the device is mapped to.




Signal strength should be greater than 30.

The signal range is between 0 and 90.

See Radio-Plus installation manual for full details

## 5.10 Programming Part Arms

### Alter Part Arms



The system can have up to 3 Part Arms.

When Part Arm 1, 2 or 3 is selected, pre-programmed zones are omitted to allow access to certain parts of the building.

## 6. Specifications

### Control Panel

#### Power supply

<b>Mains Supply Voltage:</b>	230VAC ( $\pm 10\%$ )
<b>Maximum Total Current Rating</b>	
16.5V <sub>AC</sub> , 40VA transformer:	1.5ADC
<b>Ripple</b>	<5%
<b>Rechargeable Battery Capacity</b>	1.2Ah to 17Ah

#### Electrical

##### Current Consumption

Quiescent	<50mA
Alarm (with speaker)	<150mA

##### Fuses

Mains (1.0ADC)	125mA, 250V, 20mm
Mains (1.5ADC)	500mA, 250V, 20mm
Battery	1.6A, 250V PTC
Auxiliary	900mA, 250V PTC
Bell	900mA, 250V PTC
Network 1	900mA, 250V PTC

<b>Rechargeable Battery Capacity</b>	1.2Ah to 17Ah
--------------------------------------	---------------

<b>Remote Keypads</b>	Up to four
-----------------------	------------

<b>Expanders</b>	2 8XP OR 1 8XE + 1 8XP
------------------	------------------------------

<b>Output Modules</b>	1
-----------------------	---

<b>Zones</b>	8 expandable to 24
--------------	--------------------

<b>EOL Resistor Value</b>	2k2 EOL & 4k7 contact OR 3k3 EOL & 3k3 Contact
---------------------------	--

##### Panel Outputs

O/P 1	100mA switched to 0V
O/P 2	100mA switched to 0V
O/P 3	100mA switched to 0V
O/P 4	100mA switched to 0V
O/P 5	100mA switched to 0V
O/P 6	100mA switched to 0V
PGM1	100mA switched to 0V

<b>Speaker Output</b>	Minimum load 8 $\Omega$
-----------------------	-------------------------

##### Network

+	+12V Power
-	0V Power
T	Transmitted Data
R	Received Data

### Environmental

<b>Operating Temperature</b>	-10°C (+14°F) to +55°C (+132°F)
<b>Storage Temperature</b>	-20°C (-4°F) to +60°C (+140°F)
<b>Maximum Humidity</b>	95% non-condensing
<b>EMC Environment</b>	Residential Commercial Light Industrial Industrial

### Physical

<b>Dimensions</b>	305mm x 405mm x 100mm
<b>Material</b>	2mm Steel
<b>Battery Compartment</b>	Up to two 12V 7.0Ah batteries or one 12V 17Ah battery
<b>Packed Weight</b>	5.5 Kg

## Remote Keypads

### Electrical

**Operating Voltage** 10 – 13.7VDC

### Current Consumption

Quiescent >35mA

When Fully Backlit >85mA

### Keypad Type

*Premier LCD* 32 Character standard screen LCD

*Premier LCDL* 32 Character large screen LCD

*Premier LCD/LCDP* LCD with built in Prox Reader

*Premier LCDL/LCDP* LCDL with built in Prox Reader

### Zones

Number 2

EOL Resistor Value 2k2 EOL & 4k7 Contact

### Speaker Output

O/P 1 500mA switched to 12V

### Network

4-wire standard 7/0.2 alarm cable up to 250m Star, Daisy Chain or any combination of the two

### Back Lighting

Fully adjustable

**Speaker Output (LCDL/LCDLP)** Minimum load 8Ω

**Speaker Volume (LCDL/LCDLP)** Fully adjustable

**Proximity Reader (LCDP/LCDLP)** Tag

### Environmental

**Operating Temperature** -10°C (+14°F) to +55°C (+131°F)

**Storage Temperature** -20°C (-4°F) to +60°C (+140°F)

**Maximum Humidity** 95% non-condensing

**EMC Environment** Residential  
Commercial  
Light Industrial  
Industrial

### Physical

**Dimensions** 140mm x 115mm x 30mm

**Packed Weight** 260g Approx.

## Zone Expanders

### Electrical

**Operating Voltage** 9 – 13.7VDC

### Current Consumption

Quiescent >65mA

In alarm with speaker >320mA

### Network

4-wire standard 7/0.2 alarm cable up to 250m Star, Daisy Chain or any combination of the two

### Zones

Number 8

EOL Resistor Value 2k2 EOL & 4k7 Contact

### Speaker Output

Minimum load 8Ω

### Outputs

O/P 1 100mA switched to 0V

O/P 2 100mA switched to 0V

O/P 3 100mA switched to 0V

O/P 4 100mA switched to 0V

O/P 5 100mA switched to 0V

O/P 6 100mA switched to 0V

O/P 7 100mA switched to 0V

O/P 8 100mA switched to 0V

### Environmental

**Operating Temperature** -10°C (+14°F) to +55°C (+131°F)

**Storage Temperature** -20°C (-4°F) to +60°C (+140°F)

**Maximum Humidity** 95% non-condensing

**EMC Environment** Residential  
Commercial  
Light Industrial  
Industrial

### Physical

**Dimensions** 150mm x 120mm x 30mm

**Packed Weight** 200g Approx.

## Output Expanders

### Electrical

**Operating Voltage** 9 – 13.7VDC

### Current Consumption

Quiescent >35mA

### Network

4-wire standard 7/0.2 alarm cable up to 250m Star, Daisy Chain or any combination of the two

### Bank 1 Outputs

O/P 1 100mA switched to 0V  
O/P 2 100mA switched to 0V  
O/P 3 100mA switched to 0V  
O/P 4 100mA switched to 0V  
O/P 5 100mA switched to 0V  
O/P 6 100mA switched to 0V  
O/P 7 100mA switched to 0V  
O/P 8 100mA switched to 0V

### Bank 2 Outputs

O/P 1 100mA switched to 0V  
O/P 2 100mA switched to 0V  
O/P 3 100mA switched to 0V  
O/P 4 100mA switched to 0V  
O/P 5 100mA switched to 0V  
O/P 6 100mA switched to 0V  
O/P 7 100mA switched to 0V  
O/P 8 100mA switched to 0V

### Environmental

**Operating Temperature** -10°C (+14°F) to +55°C (+131°F)

**Storage Temperature** -20°C (-4°F) to +60°C (+140°F)

**Maximum Humidity** 95% non-condensing

### EMC Environment

Residential  
Commercial  
Light Industrial  
Industrial

### Physical

**Dimensions** 150mm x 120mm x 30mm

**Packed Weight** 200g Approx.

## Communicators

### Electrical

**Operating Voltage** 9 – 13.7VDC

### Current Consumption

Quiescent >25mA

When Active >80mA

### Com300 Protocol

Fast Format  
Contact ID  
SIA Level II  
EasyCom Pager  
V.21 Modem (300 baud)

### Com2400 Protocol

Fast Format  
Contact ID  
SIA Level II  
EasyCom Pager  
SMS Messaging  
V.21 Modem (300-baud)  
V.22 Modem (2400-baud)

### ComISDN Protocol

Fast Format  
Contact ID  
SIA Level II  
EasyCom Pager  
SMS Messaging  
V.21 Modem (300-baud)  
V.34 Modem (19200 baud)

### Telephone Numbers

6 (up to 24 digits each)

### Dialling Formats

Pulse or DTMF

### REN

1

### Approval

CTR21

### Environmental

### Operating Temperature

-10°C (+14°F) to +55°C (+131°F)

### Storage Temperature

-20°C (-4°F) to +60°C (+140°F)

### Maximum Humidity

95% non-condensing

### EMC Environment

Residential  
Commercial  
Light Industrial  
Industrial

### Physical

### Dimensions

150mm x 120mm x 30mm

### Packed Weight

50g Approx.

## Standards

Conforms to European Union (EU) Low Voltage Directive (LVD) 73/23/EEC and Electro-Magnetic Compatibility (EMC) Directive 89/336/EEC.

The CE mark indicates that this product complies with the European requirements for safety, health, environmental and customer protection.

This equipment is designed to enable an intruder alarm system in which it is installed to comply with the requirements of security grades 1, 2 or 3 of EN 50131-1 and EN 50131-6 and is suitable for installation in any indoor environment.

## Warranty

All Texecom products are designed for reliable, trouble free operation. Quality is carefully monitored by extensive computerised testing. As a result the control panel is covered by a two-year warranty against defects in materials or workmanship.

As the control panel is not a complete alarm system but only a part thereof, Texecom cannot accept responsibility or liability for any damages whatsoever based on a claim that the control panel failed to function correctly.

Due to our policy of continuous improvements Texecom reserve the right to change specification without prior notice.

The *Premier 24* is protected by Community Registration Design Number: 000057211-0001. *Premier* Keypads and Expanders are protected by UK & International Registered Design. Registered Design Numbers: 2089016 and 3004996.

*Premier* is a trademark of Texecom.





## Declaration of Conformity

This declaration is valid for the following product:

**Device Type:** Intruder Alarm Control Panel  
**Product Name:** Premier 24

This is to confirm that this product meets all essential protection requirements relating to:

**EMC Directive:** 2004/108/EC

**LVD Directive:** 2006/95/EC

The assessment of this product has been based on the following standards:

<b>EN 55022 1998</b>	Emission Standard for Information Technology Equipment.
<b>EN 50024 1998</b>	Immunity Standard for Information Technology Equipment.
<b>EN 50130-4 1996</b>	Immunity Standard for Fire Intruder and Social Alarm Systems.
<b>EN 50131-1</b>	Security Grade 3, Environmental Class II
<b>PD6662: 2004</b>	
<b>EN 60950: 2000</b>	Information Technology Equipment Essential Requirements for Safety.

On behalf of the manufacturer:

**Texecom Ltd.  
Bradwood Court  
St. Crispin Way  
Haslingden  
BB4 4PW**

This declaration is submitted by:

**R J Austen  
Vice Chairman**

**12 July 2007**





**Texecom**  
**www.texe.com**

Texecom Limited, Bradwood Court, St. Crispin Way, Haslingden, Lancashire BB4 4PW, England.

**Technical Support:**

UK Customers Tel: 08456 300 600

(Calls charged at 3.36 pence per minute from a BT landline. Calls from other networks may vary.)

International Customers Tel: +44 1278 411707

Email: [techsupport@texe.com](mailto:techsupport@texe.com)

© Texecom Limited 2007

**INS248-3**